AC/DC Screw Rail Washer Replacement Kit



Replacement Washers for AC/DC Screwdrive Rails

TOOLS REQUIRED: Assorted wrenches or socket & ratchet set, screwdrivers, pliers.

- 1. UNPLUG operator from 110VAC powersource.
- 2. REMOVE operator from ceiling and place on clean flat work surface.
- 3. REMOVE rail assembly from motor head.
- 4. SLIDE screw out of rail about 6 inches.
- 5. REMOVE E-ring and old washers assembly.
- 6. INSTALL replacement washers, brearing, retaining cup and e-ring in correct order. FIG 1.
- 7. INSTALL rail assembly back into motor head.
- 8. INSTALL unit per owners manual back onto ceiling.
- 9. PLUG powercord in to 110VAC powersource.
- 10. TEST unit per owners manual.

FIG₁

