

## **Install your Seat Belt Extender**

A seat belt extender can be used if you find that your seat belt is too tight, or if you want to secure something in place that is larger than the original belt allows. To install an OEM bolt-in seat belt extender, follow these simple instructions:

**Step # 1:** Find the end of the seat belt inside the vehicle (this will be attached to the vehicle frame or the seat) and remove the original hex bolt from the seat belt.

**Step # 2:** To install the extender, simply place the bent end of the extender in the place where you just removed the seat belt. Replace the nut and bolt that you removed earlier to fix this end of the extender in place.

**Step # 3:** Insert the hex bolt you purchased with the seat belt extender through the other end of the extender (flat side). Then place it into the metal section of the seat belt that you detached from the vehicle, and through the washer and lock nut and firmly tighten.

**Step # 4:** Before you use the modified seat belt, check all connecting parts, make sure all the nuts and bolts are adequately tight, and make sure the seat belt is not twisted.