
Ready to Shine?

Get Started With Your LuminAID



Find videos and more guides at:

LuminAID.com/Get-Started

How to Check the Battery Level

- 1) Press the red 🗓 Battery Button.
- 2) First, all 4 green LED's will flash once.
- **3)** Next, the green LED's will hold steady to show the charge level.

PRO TIP: If the green LED's only flash, and do not hold steady, then your LuminAID is on low battery.



SCAN ME

How to Recharge Your Lantern

Charging by Solar Power: Charge outdoors in direct sunlight while the lantern is OFF. Your lantern can charge in cloudy weather, but it will take longer.

PRO TIP: When the red 🎉 Indicator LED shinies brightly, your lantern is getting a strong charge!

Charging by Micro-USB: A small micro-USB to USB-A cable is included for recharging your lantern. USB recharging takes 2-4 hours.



DO charge outdoors in direct sunlight



DON'T charge indoors through windows

How to Charge Your Phone

- 1) Plug the small end of your phone's charging cable into your phone. Plug the large end* into the LuminAID's USB-A output port.
- Press the red Battery Button to send a charge to your phone.
 For best performance, make sure your LuminAID is charged first.

*If your phone uses a USB-C charging cable, you may need an adapter. We sell one on LuminAID.com

Can my LuminAID charge phones?

Our 2-in-1 Power Lantern models can charge phones. Here's how to check what type you have:

Micro-USB · INPUT Port

This port is for recharging your LuminAID's internal battery by Micro-USB (cable included)

If your LuminAID only has this port, it does NOT charge phones.





USB/Solar Lantern



2-in-1 Power Lantern

USB-A OUTPUT Port Micro-USB INPUT Port

2-in-1 Power Lantern models have 2 ports:

1) USB-A OUTPUT port to charge your phone (use a your phone's charging cable)

2) Micro-USB INPUT port for recharging the internal battery (cable included)



ISB-A Cable

Micro-USB Cable