## • #4311 Temp Sender

The back of your Temperature Gauge will have a little sticker with the Temp Sender number on it. This information is helpful when calling about Temperature Gauge issues.

The 4311 Temp Sender is a small unit that is supplied with a <sup>1</sup>/<sub>2</sub> inch pipe thread adaptor for older style intake manifolds. A 3/8 inch adaptor is also available from SHIFTWORKS®.



4311 Sending Unit

The specifications for the Sender are as follows:

OHMS	TEMP	SCALE
368	100F	Low
80	212F	Mid
40	280F	High



Normal operating temperatures of 180F – 190F will put the pointer at about 1/3 scale.