


## Osprey Threaded Custom Converter FAQ: How do I remove a converter that is stuck into section?

Use rubber grip from Nib Block Kit. Wrap the rubber on the Converter and hold it firmly With left hand.



Using the right hand (as left hand holds the converter firmly with rubber grip) twist the section towards you.

**Tip:** Make-sure your converter is fully threaded in order to have best performance and flow. If you find that it is difficult to unthread or thread your converter, use a very small amount of silicone grease. Using a toothpick apply an extremely small amount and coat the threaded groove on converter or section. This should allow the converter to easily thread or unthread. Make-sure to use very small amount as you do not want to silicone grease to ever end up on your feed (which will require disassembly and cleaning as it can block ink flow).