

# CABANA



In order to familiarize yourself with your new tent, we recommend you "test pitch" before your first outing. For additional information please visit [www.kelty.com](http://www.kelty.com).

Package Includes: carry bag, Cabana body, one long fiberglass pole, two short fiberglass poles, sand bag stakes, guy line cords, and tent stakes.

1



Front Quick Corner sleeve



Lay out Cabana and stake at least one stake loop. Assemble poles, making sure all pole sections are fully connected at joints. Locate front quick corner sleeve, shown above and insert long pole, then flex pole and insert in the other front front corner sleeve.

2



Top Quick Corner sleeve



Locate one of the shorter poles and insert into the rear quick corner sleeve, then gently flex pole and insert into the top quick corner sleeve. Then repeat for second short pole.

3



Back of cabana shown: Work your way around and follow the poles from the quick corners and attach all pole clips. Reposition shelter as desired and stake out.

4



Note: front fabric can stake out for additional floor coverage or toggle up to Cabana for privacy door. Sand Bag stakes are also provided for beach use, fill with sand or bury.