



**AARDING**<sup>TM</sup>  
earth yourself

EN

## Instructions for use of Alligator Clip

**In the package:** 1 Alligator clip / 1 metal pipe strap / 2 plastic straps (Ty-Rap)

**Rule of thumb:** Attach the alligator clip to a heating pipe so that the metal of the clip touches the bare (unpainted) metal of the tube. The clip only needs to touch slightly the metal of the tube, 1 mm is sufficient. There are several solutions for this. With fully painted tubes, eg. on the invisible side, you can remove some paint (eg. by scraping).

### 3 possible attachements:

**(if you can not directly clip the crocodile clip to a piece of metal from the tube or radiator):**

- Fasten the metal pipe strap around the tube with a screwdriver. Clip the alligator clip onto the screw (or on a possibly extending lip of the metal strap).
- Secure the metal pipe strap with a screwdriver around the tube and make sure that one section of the alligator clip is clamped under the strap. This is the most robust solution, but be aware that detaching the clip afterwards will be more difficult.
- Attach a plastic strap (Ty-Rap) around the tube and ensure that one section of the alligator clip is clamped.

Note: these straps can only be used once. Once tied they can not be opened again, only by cutting them.

