



BATTERY SPECS: 18aH 14.4 Volts.

CHARGER SPECS: 110/240 volts, 50-60 Hz 100VA AC, 16.8 volts, 5 Amps DC

SAFETY WARNING: The battery and charger are well designed with proper safety measures in place, but as with any lithium-ion battery, please handle with care and use common sense. Do not drop, puncture, or disassemble the battery for any reason. Should the battery be damaged in any way, please do not use and call us immediately for assistance at (800) 774-1088. You must read the operating manual at QODGOLFUSA.COM/MANUAL prior to using your caddy.

PLEASE NOTE: Currently these batteries are forbidden on all commercial airlines.

Mini-Miser Batteries
Level 2, 26 Hotham Parade
Artarmon NSW Australia 2064
info@mini-miser.com

PLEASE READ CAREFULLY

- You will need to charge your battery prior to first use. This may take up to 8 hours.
- Charge the battery in any standard outlet that is not shared with another device. If your socket has an on/off switch, turn it off until you plug the charger into the wall.
- Always charge and store in a dry, well-ventilated area with no extreme temperatures, NO hot cars or freezing garages.
- Connect the battery to the charger before plugging the charger into the wall. When finished charging, disconnect the charger from the wall before disconnecting the battery from charger.
- A red light appears on charger while charging and turn solid green or blinking green upon completion.
- Once the charger light is green, you may disconnect and use the battery. If you are not available to disconnect the battery right away, that is ok, just disconnect as soon as you are able to.
- Always recharge your battery after each use until the charger light is green. If you don't play again for more than a week, plug the battery back in before you play and if it is solid green or blinking green, you are good to go, if it is red, let it charge until it turns green again.
- If you plan on not using your battery for more than a month, charge your battery for 3 hours and then disconnect from the wall and store in a cool, dry environment. Set a calendar reminder to charge for about two hours once a month to ensure the longevity of your battery. It does not have to be exactly a month, or exactly two hours, this is just a general guideline.
- Prior to using the battery after a long break, charge it again until the charger light turns green.
- To use the battery, place in center of the QOD and plug the cable extending from the QOD into the terminal connector on the battery. The cable will not connect if it is turned the wrong way.

Complete operating manual available at QODGOLFUSA.COM/MANUAL