



CARABINER LIGHT KIT

For videos, FAQ's, and more please visit GearAid.com/blogs/help

1 TO USE LED LIGHT:

1. Press red button and select desired light mode/setting.
2. To turn light off, press red button for 3 seconds or toggle through all modes.

Memory Feature: The light will turn back on to the last mode.

2 TO RECHARGE LED LIGHT:

1. Attach charging cord to light and plug other end to any USB port.
2. Red light will appear when charging and will turn green when charging is complete.

3 TO USE WEBBING ATTACHMENT:


1. Remove Camp Carabiner from the light and twist on webbing attachment.
2. Attach webbing using the 1" shoulder strap or 3/4" sternum strap.

4 TO ATTACH CAMP CARABINER TO 550 PARACORD:


1. Remove LED light from carabiner and twist on paracord attachment.
2. Hold Camp Carabiner up to paracord and press slot into cordage.
3. Twist clockwise to lock cord into attachment slots until anchored.

Note: Bail (sliver clip) must be closed to hold heavy items – max weight load: 25 lbs.

1



2




3



1.1




1.2




4

1.1



1.2



1.3

