

## ADJUSTABLE LED LIGHT PROVIDES 25 - 160 LUMENS

**25**  
LUMENS  
**25 Hour**  
Run Time



**160**  
LUMENS  
**5 Hour**  
Run Time

### 3 BRIGHTNESS LEVELS



Low



Medium



High



Water-Resistant

**3000 mAh**

**LITHIUM-ION  
BATTERY**



SOS emergency light feature

**4 HOURS**

The time it takes to charge  
with a 5V 2A charger.

### MOUNT IT / HANG IT

Attach to tripods and Gear Aid®,  
RAM® and GoPro® mounts.  
Hang a party lantern using  
the diffuser mantle.

- Weight:** 4.02oz (114g)  
**Dimensions:** 3.3" x 2.6" x 1.1" (85 x 66 x 27mm)  
**Battery Type:** LG Chem Lithium Ion  
**Battery Capacity:** 3,000 mAh (11 Wh)  
**Durability:** IPX4  
**USB Input:** 5V 2.1A  
**Bulb Count:** 15 LED bulbs  
**Model Number:** SP9014

**Safe to fly with. Store fully charged in a cool place.**

Emmenez-la en avion en toute sécurité. Conservez à pleine charge dans un endroit frais.  
Seguro para volar con él. Guardar completamente cargado en un lugar fresco.

**Learn more at [www.gearaid.com/tools](http://www.gearaid.com/tools)**


En apprendre plus sur [www.gearaid.com/tools](http://www.gearaid.com/tools)  
Más información en [www.gearaid.com/tools](http://www.gearaid.com/tools)

**GEAR AID®**

1-800-221-7325

SPARK™ and Gear Aid® are trademarks of Gear Aid Inc.  
Copyright ©2016 Gear Aid Inc.  
LG Chem is a registered trademark of LG Corp.  
GoPro® is a registered trademark of GoPro, Inc.  
RAM® is a registered trademark of National Products Inc.

[GEAR.AID.COM](http://GEAR.AID.COM)



**SPARK™**

**Quick Start Manual**

## THANK YOU FOR PURCHASING THE SPARK™

Merci d'avoir acheté la SPARK™

Gracias por adquirir su SPARK™

## CHARGE BEFORE FIRST USE.

Chargez avant la première utilisation.

Batería antes de usarla.

## IN THE BOX:

1 USB Charge Cable - 1 Diffuser Bag - 1 Hang Hook

## 1-YEAR LIMITED WARRANTY




Before first use, register the code below at:

[www.gearaid.com/warranty](http://www.gearaid.com/warranty)

1 AN DE GARANTIE - Avant la première utilisation, enregistrez le code ci-dessous sur: [www.gearaid.com/warranty](http://www.gearaid.com/warranty)

1 AÑO DE GARANTÍA - Antes del primer uso, registre el código de abajo en: [www.gearaid.com/warranty](http://www.gearaid.com/warranty)

REGISTRATION CODE: S P - \_ \_ \_ \_ - \_ \_ \_ \_



- 1. Power Button:** Press power button to turn on. Click through Low - Medium - High - Off. / **2. SOS Signal:** Press and hold power button for 2 seconds. / **3. Battery Indicator:** Power on to check battery level. / **4. Micro USB Power Input:** Battery is fully charged when indicator lights stop flashing. / **5. Attachment Point:** 1/4" -20 threaded attachment for tripods, Gear Aid® mounts, and the GoPro® adaptor. / **6. Kickstand:** Hold or stand-up the light with the aluminum kickstand. / **7. Hanging Lantern:** Make a party light with the included diffuser bag and hang hook.

- 1. Bouton Power:** Appuyez sur le bouton power pour allumer. Cliquez vers Faible - Moyen - Élevé - Off. / **2. Signal SOS:** Pressez et maintenez le bouton pendant 2 secondes. / **3. Voyant batterie:** Démarrez pour vérifier le niveau de la batterie. / **4. Prise d'alimentation Micro USB:** La batterie est chargée lorsque les voyants cessent de clignoter. / **5. Point d'attache:** Fixation filetée 1/4"-20 pour trépieds, supports Gear Aid®, et l'adaptateur GoPro®. / **6. Béquille:** Tenez ou posez la lampe avec la béquille en aluminium. / **7. Lanterne suspendue:** Faire une lumière de fête avec le sac de diffuseur inclus et accrocher le crochet.

- 1. Botón de Encendido:** Pulse el botón para encender. Haga clic para pasar de Bajo - Medio - Alto - Apagado. / **2. Señal de SOS:** Mantenga pulsado el botón de encendido durante 2 segundos. / **3. Indicador de batería:** Activarlo para comprobar el nivel de la batería. / **4. Entrada de energía Micro USB:** La batería está completamente cargada cuando la luz indicadora deja de parpadear. / **5. Punto de Acoplamiento:** Acoplamiento de suplemento de rosca 1/4"-20 para trípodes, soportes Gear Aid® y adaptador GoPro®. / **6. Pie de apoyo:** Mantenga o levante la luz con el pie de apoyo de aluminio. / **7. Linterna que cuelga:** Que sea una Fiesta la luz con el difusor incluido bolsos gancho para colgar.