
Wireless Charging for Apple Watch®:

Lay your Apple Watch® down onto the charging area and it will automatically be detected and begin to charge.



PRODUCT DESCRIPTION

 \frown

PRODUCT SPECIFICATIONS

Me	
	\sim

 1. Adjustable Wireless Coil
 7. Micro USB Input

 2. Non-slip Mat
 8. Airpod Charging Indicator

 3. USB A Output
 9. Gear of Wireless Coil

 4. Type C Input/Output
 10. Power Button

 5. Wireless Charging
 11. Wireless Charging Pad

 Indicator
 2. Airpod Charging Pad


Battery Capacity:	10000 mAh
Rated Capacity:	6500mAh
Type C Input:	5v/2.6A, 9V/2A
MicroUSB Input:	5v/2A, 9V/2A
USB-A Output:	5V/3A, 9V/2A, 12V/1.5A
Type C Output:	5V/2.4A, 9V/2.22A, 12V/1.67A
Wireless Output	5W, 7.5W, 10W, 15W, 20W
(Mobile):	
AirPods Output:	5W (Max)
iWatch Output:	3W (Max)
/simultaneous	5V/3A
Output:	
Dimension:	6.46 x 2.85 x 1.07 inch
	(164.1 x 72.6 x 27.4mm)
Weight:	11.81 oz (335 g)
Weight:	11.81 oz (335 g)



Scan the QR code with your phone to access the U Speakers website.

info@shopuspeakers.com @uspeakers www.shopuspeakers.com

All rights reserved to I&G designs and logistics, LLC d/b/a Fashionit U Speakers




WARNING


- The power bank stand will generate heat when charging (it is normal for the wireless charging technology). Please use it in a well-ventilated area when charging.
- Keep the power bank stand away from heat sources, direct sunlight, humidity, water or other liquids.
- Do not operate the power bank stand if it is wet or damaged to prevent electric shock and explosion. Do not repair without unauthorized.
- Do not use the power bank stand with wet hands.
- Do not use the unit for purposes other than its intended use.

When your wireless charging is not working properly

Clean the clutter on the wireless charge. Please make sure the wireless charging coil is correctly positioned with the phone coil. When the wireless charger is overheating, keep your mobile device away from the wireless transmitter. Please wait for the wireless transmitter to cool down before trying to charge it.




JUICEBAR OPERATION




Use of Switches

Press the power button once to turn the device on. The battery indicator will light up to show that it is ready to use and charge all of your devices. Double click the power button to turn the device off.


Note: if left without use for 25 seconds, the device will shut off and will need to be turned on again to charge"



When charging, the light will turn white During faulty charging the white light will flash




AirPods® charging indicator Status When the Airpod® charging pad is not in use, the light will be off When the Airpod® charging pad is in use, the light will turn white



There are two ways to recharge the Juicebar power bank when the battery is low:

You can use a Micro USB charging cable, or a Type-C standard charging cable to connect the device to a power source using the correct adapter. The Juicebar can still be used to charge your personal devices while it is being plugged in to recharge.




Insert the USB charging cable USB A end into an Output.
 Plug the other end of the cable into a terminal such as a phone.

Charging The Mobile Device

Charging Your Mobile Device:

 Place your mobile device on the wireless charger (your phone must be able to support wireless charging technology)
 Depending on the size of your mobile device, you may need to adjust the height of the wireless coil up or down to charge your phone.



Note: The wireless charger is widely compatible with compatible with all wireless charging phones.

Wireless Charging for AirPods

Lay your Airpods down onto the charging area and they will automatically be detected and begin to charge. Be sure to position the Airpods in their case in the small groove.

