# U Speakers PRO Manual

1. Speaker
2. LED indicator
3. Microphone
4. Turn on/off button
5. Hole for cord
6. Pro USB port

U speaker instructions:

- Play one Pro - turn on the speaker by pressing the power button for a few seconds until you hear a sound indicator and the blue lights come on. Turn on the device you wish to pair with the U speaker and activate the Bluetooth function. Search for Bluetooth pairing name "Uspeaker" and click to pair. The speaker will pair automatically.

- Camera remote control - To take a photo, open your camera app and click once on the power button of your U speaker. The selfie remote control will work with most social media or camera apps.

- Charging - when battery needs to be charged, the music will begin to dim. To charge the device, simply connect the Pro USB cable to a USB port. Once the red light turns off, the device is fully charged.

- Fix a disabled key board - if you experience that your keyboard has been disabled on your device while connected to the U speaker, double click the speaker power button to enable your keyboard.

- Pair two speakers for stereo surround sound - Prior to pairing, go to your bluetooth settings and select "forget device" on any Uspeaker that shows in range. Next, turn both speakers on and double click on the back button of one of the two Pro speakers. You will hear a sound indicating that the speakers are paired. The one you double clicked on will be your main speaker and will have a blinking light underneath. Go to your Bluetooth settings to find the speaker under the name "Uspeaker" and connect it. You should only have one Uspeaker connected to your device, the second speaker is paired to the first and it will pick up the signal. Now you can play your music and enjoy your stereo surround sound. You can take a selfie picture with your main speaker.

*After the first pairing of 2 Pros, the speakers will pair automatically anytime they are turned on, as long as the Bluetooth settings have not been changed.