



What's in the box



U BOT





TYPE-C Charging Cable

Manual

LED light indicator settings

GREEN light steady: The device is turned on and will track face and movement.

GREEN light flashing: The device is on pause.

RED light flashing: The battery is low and needs to be charged.

Charging port indicator:

Red light steady: The device is being charged. The light will turn off when the U BOT is fully charged.

Operating instructions

- To turn the U BOT "ON", Press the Power button and hold for 5 seconds.
- Once the green light is on, the U BOT is in auto-tracking mode. The U BOT will track the human figure and rotate 360 degrees, ensuring that the human figure is in the center of the shot.
- To ensure the best tracking effect, keep a distance between 3 feet and up to 26 feet and only have one dynamic target in the tracking range.
- To "Pause", while the U BOT is ON, click the Power button once.
- To turn the U BOT "OFF", press the Power button and hold for 5 seconds until the unit shuts down.

Notes

- The U BOT device utilizes auto-tracking to assist with taking pictures, recording videos, video calling and live video streaming.
 If other dynamic targets appear outside the tracking range, the tracking of the main target will not be interfered but if they appear in the tracking range, the device may randomly track them according to the magnitude of the motion.
- 3. Screw hole on the bottom: Supports UNC 1/4-20-2A interface tripod.

Maintenance Notes

- 1. Do not forcefully press or twist the device as it may cause damage to the internal structure.
- 2. For optimal results keep the U BOT sensor lens clean as this may affect the tracking quality of the device.

Product parameters

Dimensions: D 120mm x H 145mm

Weight: 330g

Battery capacity: 200mAh

Operating time: 8h Charging time: 1h

Charging input: 5V===2A

Charging interface: Type-C

Suggested use distance: 1~8m, 3.2 feet-26 feet

