


U Buds BT 5.0 version English manual



Welcome!


Thank you for choosing our U Buds. Get ready to experience superior sound! Please read this manual carefully before use.

Features

- Auto power on/off and pair
- Cord free fit with flexible wearing options
- U Buds case provides instant charge
- Ultra light earpieces with wingtips for secure fit
- High quality stereo sound
- Noise reduction for better call quality
- Can be used as two individual headsets
- Voice assistant activation


1

Overview



2

What's Included




3

Charging The U Buds Case

The U Buds come with a portable charging case that includes a built-in rechargeable battery.

To charge the case, connect the micro-USB cable to the micro-USB port on the back of the U Buds case, and the standard USB connector to a USB power source such as a computer or 5V USB adapter (not included). The charging indicator lights up when the case is charging. When charging is complete, the lights will turn off. On a full charge, the case will provide an extra 3-4 full charges.




4

Charging The U Buds


Place the U Buds inside their carrying case and they will begin to charge automatically. The charging indicators will light up when the ear buds are charging and turn off when the charge is complete.

Please note: The left LED indicator indicates the charging state of the left U Bud and the right LED indicator indicates the charging state of the right U Bud. Additionally, the LED indicators on the U Buds case will flash slowly when the battery level of the U Buds case is low.



5

How to Wear



6

How to Pair

The U Buds can work separately as single headsets (mono mode) or can be used together as a pair of stereo ear buds (TWS mode).

1. Begin with both U Buds powered off (in the case) and fully charged
2. The U Buds will power on and pair with each other automatically when taken out of their case.
3. Place the U Buds in your ears and you will hear voice prompts in the following order: "Power On"> "Pairing"> "Connected"> "Left Channel" for the left U Bud and "Right Channel" for the right U Bud.
4. Enable your smartphone's Bluetooth function and select "U Buds" on your mobile device to connect the U Buds to your smartphone. You will hear a voice prompt that says, "second device connected".

7

NOTE 1: Your U Buds must be paired to each other before they can pair to your mobile device.
NOTE 2: Short temporary cut outs between the U Buds connection may happen occasionally. This is normal for wireless ear buds, however if the connection cuts out intermittently, please try to stay away from nearby radio or WIFI interference.

Power On/Off Directly From The U Buds

The U Buds will power off automatically when placed inside of their carrying case and power on automatically when they are taken out. If you would like manually turn the U Buds on and off, please follow these steps: To power the U Buds on, press and hold the multi-function button on BOTH U Buds for about 3 seconds. To power the U Buds off, press and hold the multi-function button on EITHER ONE of the U Buds for about 4 seconds.

8

Mono Headset Mode

1. Select one U Bud to pair with your smartphone.
2. Take the U Bud out of the case and wear it. It will power on automatically. You will hear the earbud announces "Pairing".
3. Enable your smartphone's Bluetooth pairing function and select "U Buds" in the Bluetooth device list to pair.
4. Once the earbud is successfully paired, you will hear voice prompt announces "Connected".

NOTE: It may be necessary to turn the second earbud off by holding the multi-function button for about 4 seconds if you choose to use only one U Bud in mono headset mode.

9

Left U Bud - Button operations

Function	Operation
1.Power On	Press & hold the Multi-function button for 3 second
2.Power Off	Press & hold the Multi-function button for 4 seconds
3.Answer a call	One tap on the Multi-function button when call is coming
4.Hang up	One tap on the Multi-function button during a call
5.Reject calls	Press and hold the Multi-function button
6.Play/pause music	One tap on the Multi-function button
7.Activate voice assistant	Press & hold the Multi-function button for 1 second
8.Next	Double-tap the Multi-function button
9.Previous	Triple-tap the Multi-function button

Right U Bud - EQ Button operations

When playing sound, double tap to switch between 5 different EQ settings: balanced, bass booster, vocals booster, treble booster and enhanced sound.

10

Activate Voice Assistant

Some mobile devices have voice assistant feature. Your U Buds may activate voice assistant on your mobile device. To activate, make sure the U Bud is paired, then press and hold the multi-function button for 1 second and release. *Not all mobile devices support this feature.

Auto Power Off

U Buds will automatically power off if they are not connected for 10 minutes.

Clear the earbuds pairing list

Place the earbuds into the slots of their charging case. Press & hold the multi-function button on each earbud for 8 seconds, until led indicators on the earbuds flash for 1 second. Delete U Buds from the Bluetooth list on your mobile device. Your U Buds are now ready to connect.

11

LED Indicators

	Status	Indication
Earbuds	Stereo Pairing:	Blue light and red light flash alternately
	Pair with bluetooth devices:	Blue light and red light flash alternately on the main earbud
	No connection:	Red light flashes slowly
Earbuds Case	Charging U Buds:	Front charging indicators light up
	U Buds case low battery:	All lights on the case flash slowly
	Charging U Buds Case:	Back charging indicator lights up

* Please note that the positions of the LED indicators on the two U Buds are located differently. Please check Overview in page 2.

12

Specifications

Model:	U Buds
Wireless connection:	V5.0(May subject to update)
Max.transmission distance:	up to 10m (No Obstacle)
Supported profiles:	AVRCP/HSP/HFP
Talk time:	3~4hrs
Music time:	2.5~3hrs
Input voltage:	Charged by DC 5V USB
Battery:	Built-in Li-polymer battery
Size:	1"x1"x1.1"(Earbud), 2.9"x1.5"x1.4"(Charging case)

13

Maintenance

- Keep this product away from heat and humidity;
- Do not put this product under direct sunlight or hot areas. High temperatures will shorten lifespan of the product;
- Charge this product if it is not used for more than 2 weeks;
- To avoid risk of electrical shock, do not disassemble the product at any time;
- Do not drop or knock this product on hard surfaces;
- Do not use chemicals or detergents to clean the product;
- Do not expose this product to rain or liquid.

14

Cautions

- To avoid accidental ingestion, keep the earbuds away from small children and pets. The earbuds contain a lithium-ion battery, and may be hazardous if swallowed. When not in use, store the earbuds in the charging case with the lid closed.
- Use caution and follow applicable laws regarding mobile phone and headphone use if using the earbuds for phone calls while driving.
- Do NOT use the earbuds at a high volume for any extended period.
- Focus on your safety and that of others if you use the earbuds while engaging in any activity requiring your attention, e.g., while riding a bicycle or walking in or near traffic.

Troubleshooting

- Earbuds don't power on
Place the earbuds in the charging case to initiate charging.
- Earbuds are not paired after taking out from the charging case.
Place the earbuds back in the case and take them out to try again.
- No sound
Increase the volume on your mobile device and make sure it is not muted.
- Earbuds don't connect with mobile device
Move your mobile device closer to the earbuds and away from any interference or obstructions.
- Charging case doesn't charge the earbuds
Make sure the earbuds are properly placed in the charging case. The charging case maybe out of battery. Please charge the case.
- Earbuds powered on themselves inside the case.
Happens when the battery of the charging case died causing the current inside to stop and triggered the earbuds to power on. Please charge the charging case.



IPX4 Water resistance rating

Protects from splashing water, no matter the direction. Rain and sweat resistant.
Note: Don't expose to water jets or sink in water.