

70x110mm




U EVOLVE WIRELESS HEADPHONES - MANUAL -



www.justfashionit.com www.uspeaker.com

Included:

- The box contains the following items:
- Wireless Active Noise Cancelling headset
- Manual
- 3.5mm Audio Cable
- Micro USB Charging Cable
- Hard Case



Charge the Battery:

This headset includes a Micro USB cable that can be connected to your computer or other USB ports. Once the cable is plugged in, the indicator light will be red while charging. Once fully charged, the indicator light will be blue. Charge time is 2-3 hours on empty battery.

Active Noise Cancelling On:

Push up the ANC button and a green LED light will turn on to indicate the ANC function is powered on. The ANC function is available with both wired and wireless connection.

Active Noise Cancelling Off:

Push down the ANC button and the green LED light will turn off. The ANC function must be turned off manually.

Bluetooth Switch On:

To switch on, press and hold the power button for 3 seconds. The headset will automatically enter Bluetooth searching mode, indicated by the LED blue light and red light flashing alternately. Once paired with a Bluetooth streaming device, a steady blue light will appear.

Bluetooth Switch Off:

To switch the headset off, press and hold the power button for 3 seconds. The LED light indicator should show a steady red light which quickly disappears.

Pairing:

1. Ensure the Bluetooth device is switched on.
2. Power on the headset. The headset will enter pairing mode automatically. The red and blue indicator light will start flashing alternately.
3. Go into your Bluetooth settings on your Bluetooth device and ensure the Bluetooth function is on.
4. Your device will begin searching for devices to connect to. Click on "U EVOLVE Headphones" and place the headphones on your ears.
5. You should hear a tone indicating that the headphones are connected. The LED light indicator will show a steady blue light.

If the headset has been previously paired with another device, it will automatically connect with that device when they are powered on and in connecting range.

Adjust the volume:

Turn the volume up or down by a quick click on the volume +/- key during a call or while listening to music. When you have reached maximum volume you will hear a warning tone.

Application:

The U Evolve headset can make and receive calls hands-free with your Bluetooth compatible phone within 33 feet of each other. The headset is compliant with Bluetooth 5.0 and supports the following profiles: Headset Profile (HSP) V1.6, Hands-free Profile (HFP) V1.7, Advanced Audio Distribution Profile (A2DP) V1.3, and Audio Video Remote Control Profile (AVRCP) V1.5 input rating 5V DC, 0.5A

Phone Calls:

To make a call, pair your phone with the headset, and follow your normal steps to making a call. Quickly press the power button twice to call the last number on your call list. When answering an incoming call, quickly press the power button to answer or hold the power button down for 2 seconds to reject the call. To end a phone call, quickly press the power button once. If you receive or make a call while listening to music, the music is paused until the call ends.

Play Music:

To play a song, select it on your music player and press play or pause either on your streaming device or your headset power button. To select the next song during playback, press and hold "+". To select the previous song, press and hold "-". To increase the volume, quickly press the "+" key, there will be a beep tone when it has reached max volume. To decrease the volume, quickly press "-" key.

Disconnect the Headset :

To disconnect the headset from your device, switch off the headset or disconnect the headset in the Bluetooth Settings on your device.

Reconnect the Headset :

To connect your headset to your Bluetooth device that it was last paired to, switch on the headset or make the connection through the Bluetooth settings on your device.

Aux cable / Passive Mode:


To save battery life, you can use the U Evolve headset with the Aux cable from the box. Using the Aux cable will disable the wireless option.

Low Battery Warning:

When your headset needs to be charged, there will be a warning beep tone every 60 seconds. When your battery voltage is lower than 2.9 V, the headset will switch off automatically.

Case instructions:

Turn both ear cups so that they are laid flat. Fold the right ear cup inward towards the headband. From there the headphones should fit perfectly in their case.



Specification:

- Chipset: QCC
- Driver unit: 40mm
- Impedance: 32Ω
- Driver unit frequency: 20Hz-20KHz
- Headset sensitivity: 97dB±3dB
- Microphone sensitivity: -42dB
- Bluetooth edition: Bluetooth V5.0
- Radio Frequency coverage: 2.402GHZ-2.480GHZ
- Transmit Range: about 10m (barrier free)
- Frequency Response: 20HZ-20KHZ
- Active Noise Cancelling: up to 28dB during 100-1000Hz
- Status Indication: LED<blue> flash slowly (under Bluetooth mode)
- Pairing products: Bluetooth computer with HFP, A2DP, AVRCP, Bluetooth protocol, USB Bluetooth adapter, Bluetooth cell phones, etc.
- Battery: Rechargeable lithium ion battery; 3.7V, 300mAh
- Charge: Computer USB interface, output DC 5V/300Ma charger
- Charging time: up to 3 hours
- Operate hours: up to 20 hours (battery saturation)
- Standby time: up to 200 hours (battery saturation)

Caution

1. Do not try to change the battery in the headset yourself.
2. The headset is not water resistant and needs to be stored in a dry area.
3. Do not place this headset in an environment with over 140°F degrees, or into fire, to avoid a battery blast incident.
4. Do not bend or twist the bracket to avoid deformation.
5. Be sensitive to the volume level. If the volume becomes uncomfortable, turn down the volume to avoid any hearing damage .
6. Do not use the headset while driving or where you cannot be aware of your surroundings.

Para obtener el manual en Español, por favor ingresa a:
www.justfashionit.com/pages/manuals



U EVOLVE WIRELESS HEADPHONES - MANUAL -



www.justfashionit.com www.uspeaker.com