

Charging the battery

1. Insert the included charging cable into the type-C port on the bottom of the speaker and plug it into a power source. You will see an LED light indicator turn on, showing that the speaker is charging.
2. After the speaker is fully charged, the LED light indicator will turn off.

Bluetooth pairing

1. Turn the speaker on by holding the power button down for a few seconds until you hear a sound indicator and the LED lights come on.
2. Turn on the device you wish to pair with the U Speaker-Hydro and activate the Bluetooth function. Search for the Bluetooth pairing name "U Speaker-Hydro" and click to pair. You will hear a sound indicating that the speaker has paired automatically.

Stereo mode (for two speakers only)

1. Begin by clearing all U Speakers from your Bluetooth list by selecting "Forget Device" and make sure that NO other devices around are connected (like an iPad, laptop etc.)
2. Turn both speakers on. Next, double click the power button on one of the speakers and wait until you hear a sound indicating that the speakers have successfully paired. One speaker should have a flashing light, and the other speaker should have a solid light.
3. Turn on the Bluetooth function on your device. You will see two options for the "U Speaker-Hydro" on your Bluetooth list. Wait up to 20 seconds, until only one "U Speaker-Hydro" option is visible and select to pair. You will hear a sound indicating that the speaker has paired automatically.



Check out our full line of products!

www.shopuspeakers.com



Scan the QR code with your phone to access the U Speakers website.

info@shopuspeakers.com @uspeakers
www.shopuspeakers.com

Designed by Fashionit/U Speakers in the USA.
Made in China 2023, All Rights Reserved to I&G
Designs and Logistics. DBA Fashionit® U Speakers®



Shower & Outdoor Speaker
USER MANUAL

U HYDRO

Instructions for controls

(See the speaker diagram on the next page for reference)

Turn the speaker on:

Press the power button for 2 seconds.

Changing volume:

To increase volume: Hold down the Volume Increase button.

To decrease volume: Hold down the Volume Decrease button.

To change songs:


Skip a song: Click the volume increase button once.

To go to previous song: Click the volume decrease button once.

To Play/Pause: Click the power button once. If you are receiving a call while connected to the speaker, you may follow the same instructions to reject the incoming call.

To use the LED light function: Hold down the LED light button to activate the color changing option. The default setting will show the lights changing along with the beat of the music played. If you prefer a solid color to be displayed, click on the LED light button until you reach the desired color choice. To turn the light off, hold down the LED button until the light is off.

Camera remote control: To take a photo, open your camera app and click the M button on your speaker twice to take a picture. The selfie remote control will work with most social media or camera apps.



1. Elastic band
2. Speaker
3. LED indicator
4. TYPE-C port
5. Volume Decrease button
6. Power button
7. LED light button
8. Microphone
9. Volume Increase button



Water Resistance

IPX6: Can resist high-pressure, heavy sprays of water. Don't submerge in water.

Specifications

Power Rating	4W
Frequency Response	20HZ-16KHZ
THD	<1%
S/N	≥80DB
Speaker Parameter	4Ω 4W diameter 45mm
Battery	3.7V/ 700mAh
Bluetooth Version	V5.0
Product Size	ø70X48mm
Product Weight	156g