## **TEMPORARY POWER SOLUTIONS**

	RANSFER			EXTENSION CORD SETS		
Rating	Pin Config. MALE Power Source	Compact Adapter	Flexible Adapter	We offer different lenth extension cables to help reach your generator from further distances.		
<b>15A</b> 125V	5-15	AD515L1430	S515L1430- 012	NEMA 5-15P         15/20AEX-010 (10 Ft.)           15/20AEX-025 (25 Ft.)         15/20AEX-025 (25 Ft.)           15/20AEX-050 (50 Ft.)         15/20AEX-050 (50 Ft.)		
<b>20A</b> <sup>125/</sup> <sup>250V</sup>	(x y) L14-20	ADL1420L1430	L1420L1430- 018	NEMA 5-20P         S520PR-010 (10 Ft.)           S520PR-025 (25 Ft.)         S520PR-025 (25 Ft.)           S520PR-050 (50 Ft.)         S520PR-050 (50 Ft.)		
125V	L5-30	ADL530L1430	L530L1430- 018	NEMA L5-20P         L520PR-010 (10 Ft.)           Available in 10, 25,         50, 75, and 100 feet.		
<b>30A</b> 125V	<b>TT-30</b>	ADTTL1430	TT30L1430- 018	NEMA 6-20P S620PR-010 (10 Ft.) S620PR-025 (25 Ft.) S620PR-050 (50 Ft.)		
125/ 250V		AD1430L1430	\$1430L1430- 018	NEMA L6-20P         L620PR-010 (10 Ft.)           Available in 10, 25,         50, 75, and 100 feet.		
<b>50A</b> 125/ 250V		AD1450L1430	\$1450L1430- 018	NEMA L14-20P         L1420PR-010 (10 Ft.)           Available in 10, 25,         50, 75, and 100 feet.		
	RANSFER			NEMA L5-30P         L530PR-010 (10 Ft.)           Available in 10, 25,         50, 75, and 100 feet.		
Rating	Pin Config. MALE Power Source	Compact Adapter	Flexible Adapter	NEMA TT-30P TT30PR-010 (10 Ft.) Available in 10, 25,		
<b>15A</b> 125V	5-15	AD515L1420	S515L1420 -012	50, 75, and 100 feet. GENERATOR TIPS 1. Never use your generator in your home, office, garage, carport or screen porch. The exhaust can		
<b>30A</b> 125/ 125V 250V	L5-30	ADL530L1420	L530L1420- 018	<ul> <li>cause sickness or even death.</li> <li>2. Keep your generator at least 10 feet from your house. The exhaust can melt your vinyl siding.</li> <li>3. Use a battery-powered Carbon Minoxide detector when running your generator.</li> <li>4. NEVER plug your generator into your home outlet.</li> <li>5. NEVER operate under wet conditions. Try to protect the generator from rain and snow.</li> <li><i>Tips from the National Safety Council www.NSC.org</i></li> </ul>		
	L14-30	ADL1430L1420	L1430L1420- 018			
<b>50A</b> 125/ 250V		AD1450L1420	\$1450L1420- 018	24/7 Customer Service (414) 434-2220 Text Questions to (414) 323-3240 Email: Info@ACConnectors.com To Purchase: www.ACWORKS.com		

CONTACT US IF YOUNEED HELP. Version 11, ©2019 Cordtec Power Corp.

1

## **TEMPORARY POWER SOLUTIONS**

		NSFER SV LET BOX L		ASL530PBX		EXTENSIO	ON CORD SETS
Rat	ting	Pin Configuration Male Power Source	Compact	Adapter Fle	xible Adapter	NEMA I	_6-30P L630PR
<b>15A</b>	125V	5-15		AD515L530 💕	S515L530 -018		Available in 10, 25, 50, 75, 100 feet.
A	125V	5-20		AD520L530 🝼	S520L530 -018		L1430PR Available in 10, 25, 50, 75, 100 feet.
20A	125V	L5-20	1	ADL520L530	•018	NEMA :	SS1-50P SS1PR Available in 10, 25, 50, 75, 100 feet.
30A	125V	ТТЗОР	<b>)</b>	ADTTL530	TT30L530 -018	NEMA :	552-50P TESS2 Available in 10, 25, 50, 75, 100 feet.
ĩ	125/ 250V	L14-30	<b>)</b>	ADI.14301530 💕	(11430L530) -018		
							GENERATOR
		NSFER SV ET BOX CS		ASSOAPBX		Transfer Switch Circuit Breaker	
Rat					xible Adapter	Transfer Circuit	
Rat <b>12</b> 4	INL	ET BOX CS	6365			Plug one end of your cabl	e into the generator and the other end lapter. Plug the adapter into the inlet d to the transfer switch, which is wired
20A 15A Lea	INL ing	ET BOX CS	6365	Adapter Fle	xible Adapter	Plug one end of your cabl into your AC WORKS® ac box. The inlet box is wire to your circuit breaker or If you have questions reg inlet box or power adapte team. Our customer serv are unsure about your el	e into the generator and the other end lapter. Plug the adapter into the inlet d to the transfer switch, which is wired chosen power load. arding the connection of AC WORKS <sup>®</sup> rs, please contact our customer service vice is available 24/7 every day. If you ectrical contact a certified electrician
20A 15A	INL ing 132V	ET BOX CS	6365	Adapter Fle	xible Adapter TES515 -018 TEL1420	Plug one end of your cable into your AC WORKS® actions regeneration of your circuit breaker or If you have questions regenerated by a power adapted team. Our customer server are unsure about your elector instal the inlet box for Visit us on Face Follow us on	e into the generator and the other end lapter. Plug the adapter into the inlet d to the transfer switch, which is wired chosen power load. arding the connection of AC WORKS <sup>®</sup> rs, please contact our customer service vice is available 24/7 every day. If you ectrical contact a certified electrician
15A	125/ 125V 250V 125V	ET BOX CS Pin Configuration Male Power Source 5-15 (****) L14-20	6365	Adapter Fle	xible Adapter TES515 -018 TEL1420 -018 TEL530	Plug one end of your cable into your AC WORKS® actions regeneration of your circuit breaker or If you have questions regenerated by a power adapted team. Our customer server are unsure about your elector instal the inlet box for Visit us on Face Follow us on	e into the generator and the other end lapter. Plug the adapter into the inlet d to the transfer switch, which is wired chosen power load. Transfer service vice is available 24/7 every day. If you ectrical contact a certified electrician you.