





Instructions

Three-Tier Fitness Ball Rack

WARNING

- Prior to assembly, remove the components from the box and verify that all the listed parts were supplied.
- Please make sure all bolts, nuts and washers are tightly fastened.
- Please refer to diagram for installation.
- The unit should only be used on a level surface and is intended for indoor use only.

BODY SPORT SELLS THIS PRODUCT AS-IS AND MAKES NO WARRANTY, EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ALL SUCH WARRANTIES BEING HEREBY EXPRESSLY EXCLUDED.



No.	Description	Quantity
1	Frame	3
2	Vertical Tube	4
3	M6 x 40 Bolt	24
4	6 Washer	48
5	M6 Nut	24
6	Tube End Cap (pre-assembled)	4
7	Caster	4