

LBC-400~1000 ASSEMBLY INSTRUCTIONS

PARTS TABLE

| REF NO | DESCRIPTION | Qty | | | | |
|------------------------------|---------------------------------|---------|---------|---------|---------|----------|
| | | LBC 400 | LBC 500 | LBC 600 | LBC 800 | LBC 1000 |
| 01-01 | Base Plate-A | 6 | 6 | 8 | 8 | 8 |
| 01-02 | Ring Frame | 6 | 6 | 8 | 8 | 8 |
| 01-03 | Truss Pipe-A1 | 6 | 6 | 8 | 8 | 8 |
| 01-04 | Truss Pipe-A2 | 6 | 6 | 8 | 8 | 8 |
| 01-06 | Tie Rod | 6 | 6 | 8 | 8 | 8 |
| 02-01 | Water Sump | 1 | 1 | 1 | 1 | 1 |
| 02-02 | Outlet Nozzle | 1 | 1 | 1 | 1 | 1 |
| 02-03 | Inlet Nozzle | 1 | 1 | 1 | 1 | 1 |
| 02-04 | Over Flow Nozzle | 1 | 1 | 1 | 1 | 1 |
| 02-05 | Drain Nozzle | 1 | 1 | 1 | 1 | 1 |
| 02-06 | Automatic Filler Nozzle | 1 | 1 | 1 | 1 | 1 |
| 02-08 | Floater Valve Assy | 1 | 1 | 1 | 1 | 1 |
| 02-09-01 | Over Flow | 1 | 1 | 1 | 1 | 1 |
| 02-09-02 | Over Flow Connector Pipe | 1 | 1 | 1 | 1 | 1 |
| 02-10 | Suction Strainer | 1 | 1 | 1 | 1 | 1 |
| 02-12A | Connector Pipe | 1 | 1 | 1 | 1 | 1 |
| 03-01 | Water Basin | 12 | 12 | 16 | 16 | 16 |
| 04-01 | Base Plate-B | 6 | 6 | 8 | 8 | 8 |
| 04-02 | Stiffener Ring-1 | 6 | 6 | 8 | 8 | 8 |
| 04-03 | Truss Pipe-B1 | 6 | 6 | 8 | 8 | 8 |
| 04-04 | Truss Pipe-B2 | 6 | 6 | 8 | 8 | 8 |
| 05-01 | Casing(Diffuser) | 12 | 12 | 16 | 16 | 16 |
| 05-02 | Casing (Cylinder) | 12 | 12 | 16 | 16 | 16 |
| 05-06 | Hand Hole Cover | 1 | 1 | 1 | 1 | 1 |
| 06-01 | Stand Pipe | 1 | 1 | 1 | 1 | 1 |
| 06-02 | Stand Pipe Base | 1 | 1 | 1 | 1 | 1 |
| 06-03 | Packing | 1 | 1 | 1 | 1 | 1 |
| 07-02 | Column | 2 | 2 | 2 | 2 | 2 |
| 08-01 | Filling Supportor-A | 6 | 6 | 8 | 8 | 8 |
| 08-02 | Filling Supportor-B | 6 | 6 | 8 | 8 | 8 |
| 08-03 | Filling Supportor-C | 18 | 18 | 24 | 24 | 24 |
| 08-04 | Filling Supportor Clamping Band | 12 | 12 | 16 | 16 | 16 |
| 08-06 | Filling Supportor-E | - | - | 16 | 16 | 16 |
| 10-01-1 | Ladder(A Sec-1) | 1 | 1 | 1 | 1 | 1 |
| 10-01-2 | Ladder(A Sec-2) | - | - | 1 | 1 | 1 |
| 10-02 | Ladder(B Sec) | 1 | 1 | 1 | 1 | 1 |
| 10-03 | Ladder Bracket-A | 2 | 2 | 2 | 2 | 2 |
| 10-04 | Ladder Bracket-B | 2 | 2 | 2 | 2 | 2 |
| 11-01 | Filling Inner Sec | 2 | 2 | 2 | 2 | 2 |
| 11-03 | Filling 1.3 Sec | - | - | 6 | - | - |
| 11-06 | Filling 1.6 Sec | - | - | - | 12 | - |
| 11-08 | Filling 1.8 Sec | 16 | 16 | 16 | - | - |
| 11-10 | Filling 1.10 Sec | - | - | - | 20 | - |
| 12-01 | Sprinkler Head | 1 | 1 | 1 | 1 | 1 |
| 12-02 | Center Post | 1 | 1 | 1 | 1 | 1 |
| 12-03 | Turnbuckle | 6 | 6 | 8 | 8 | 8 |
| 12-04 | Tension Wire | 6 | 6 | 8 | 8 | 8 |
| 13-01 | Sprinkler Pipe | 6 | 6 | 8 | 8 | 8 |
| 13-02 | End Cap | 6 | 6 | 8 | 8 | 8 |
| 13-03 | Eliminator | 6 | 6 | 8 | 8 | 8 |
| 14-01 | Motor Frame Assy Main Pipe | 2 | 2 | 2 | 2 | 2 |
| 14-02 | Motor Frame Assy Stay Pipe | 2 | 2 | 2 | 2 | 2 |
| 15-01 | Motor Base | 1 | 1 | 1 | 1 | 1 |
| 15-02 | U-Bolt | 4 | 4 | 4 | 4 | 4 |
| 15-03 | U Bolt | 4 | 4 | 4 | 4 | 4 |
| 16-01 | Motor | 1 | 1 | 1 | 1 | 1 |
| 16-02 | Speed Reducer | 1 | 1 | 1 | 1 | 1 |
| 16-03 | Fan Key | 1 | 1 | 1 | 1 | 1 |
| 16-04 | Fasten Nut | 1 | 1 | 1 | 1 | 1 |
| 16-05 | Lock Nut | 1 | 1 | 1 | 1 | 1 |
| 17-01 | Fan Hub | 1 | 1 | 1 | 1 | 1 |
| 17-02 | Fan Blade | 4 | 4 | 4 | 4 | 4 |
| 17-04 | U-Bolt | 8 | 8 | 8 | 8 | 8 |
| 18-01 | Fan Guard | 4 | 4 | 4 | 4 | 4 |
| 19-00 | Basin Supportor Assy | 12 | 12 | 16 | 16 | 16 |
| 20-01 | Louver Supportor | 36 | 36 | 48 | 48 | 48 |
| 20-01B | Louver Supportor-B | 36 | 36 | 48 | 48 | 48 |
| 20-02 | Inlet Louver | 18 | 18 | 24 | 24 | 24 |
| 20-08 | Wing Bolt | 108 | 108 | 144 | 144 | 144 |
| 20-09 | Plastic Washer | 108 | 108 | 144 | 144 | 144 |
| OTHERS | BOLTS & NUTS | 1 Set | 1 Set | 1 Set | 1 Set | 1 Set |
| WATER BASIN SEALING MATERIAL | | | | | | |
| A | Fiberglass | 1 Set | 1 Set | 1 Set | 1 Set | 1 Set |
| B | Polyester Resin | 1 kg | 1 kg | 1 kg | 1 kg | 1 kg |
| C | Catalyst | 1 Bcme | 1 Bcme | 1 Bcme | 1 Bcme | 1 Bcme |

* Please Check The Above Mentioned Parts Within Two Weeks After The Goods Received

