

# LBC-40~60 ASSEMBLY INSTRUCTIONS

## PARTS TABLE

REF NO	DESCRIPTION	Qty		
		LBC 40	LBC 50	LBC 60
02-02	Outlet Nozzle	1	1	1
02-03	Inlet Nozzle	1	1	1
02-04	Over Flow Nozzle	1	1	1
02-05	Drain Nozzle	1	1	1
02-06	Automatic Filler Nozzle	1	1	1
02-08	Float Valve Assy	1	1	1
02-09	Over Flow	1	1	1
02-10	Suction Strainer	1	1	1
02-12A	Connector Pipe	1	1	1
02-16	Elbow	1	1	1
02-19	Inlet Pipe	1	1	1
03-00	Water Basin	1	1	1
04-00	Casing Supportor	4	4	4
05-01A	Casing	4	4	4
05-06	Hand Hole Cover	1	1	1
06-01	Stand Pipe	1	1	1
06-04	Stand Pipe Base	1	1	1
07-01	Stopper	2	2	2
08-01	Filling Supportor-A	4	4	4
08-03	Filling Supportor-C	4	4	4
10-00	Ladder	1	1	1
10-03	Ladder Bracket-A	2	2	2
10-04	Ladder Bracket-B	2	2	2
11-00	Filling	2	2	2
12-01	Sprinkler Head	1	1	1
12-04	Tension Wire	2	2	2
13-01	Sprinkler Pipe	4	4	4
13-02	End Cap	4	4	4
13-03	Eliminator	4	4	4
13-04	Lock Nut	4	4	4
14-00	Motor Frame Assy	1	1	1
16-01	Fan Motor	1	1	1
16-03	Fan Key	1	1	1
16-04	Fasten Nut	1	1	1
17-00	Fan Assy	1	1	1
17-01	Fan Hub	-	-	1
17-02	Fan Blade	-	-	3
17-04	U-Bolt	-	-	6
18-01	Fan Guard	2	2	2
20-02	Inlet Louver	8	8	8
20-01A	Louver Supportor	8	8	8
20-01B	Down Plug	8	8	8
20-01C	Up Plug	8	8	8
20-08	Wing Bolt	16	16	16
20-09	Plastic Washer	16	16	16
OTHERS		BOLTS & NUTS 1 Set		
WATER BASIN SEALING MATERIAL				
A	Fiberglass	1 Set		
B	Polyester Resin	1 Keg		
C	Catalyst	1 Bottle		

\* Please Check The Above Mentioned Parts Within Two Weeks After The Goods Received

