

# 5" Rearview Mirror Monitor VTM50M User's Manual

Thank you for choosing BOYO



# TO User

Dear User, Thank you for Choosing and using our Rearview Mirror Monitor. We are going to provide the best products and best services to you.

To insure the best performance and avoid any false alarm or function failure, please kindlly read this manual carefully and install it accordingly. When you are using this Rearview Mirror Monitor, we believe that you have read and know about all the contents of this manual. Any loss caused by operation in violation of this manual, is nothing to do with our company, nor within the coverage of warranty. The Company is not responsible for any loss caused by illegal operation.

Please obey the traffic rules and laws to drive carefully. The car monitor is just an auxiliary tool. Our company is not responsible for any traffic accident caused by driver's breaking traffic rules.

The content and pictures in this manual are checked strictly. Considering the factor of upgrading product, Pictures are only for your reference. Please use to the actual product instead

### PARTS











Monitor

r Cable

Manual


Bracket

Warranty x1 t Registration Cardx1

# **SPECIFICATION**

Input Voltage	DC 9~16V
Input Current	0.3 A
Monitor	5" Digital TFT LCD SCREEN With Touch Key
Video Input	Two Ways Video
Aspect Ratio	16:9
<b>Dual Mounting Solution:</b>	Clip-on And Replace Mounting Bracket
Work Temperprature	-20℃~70℃
Store Temerprature	-30℃ ~ 80℃
Resolution	800(H)xRGBx480

## INSTALLATION INSTRUCTION



### NOTICE

- 1. The product working voltage is DC12V. To avoid the product burn out, don't connect the monitor to the power above specification.
- connect the monitor to the power above specification.

  2. The product is not water-proof. To avoid the product short-circuit, don't let the water or other liquid into it.
- The TFT monitor of this product is fragile. To avoid the monitor broken, don't pressure, hit or throw it.

# TROUBLE SHOOTING

- No display on the monitor?

  Please check whether the power wire and AV signal plugs connected correctly.
- Does not display when reversing.
   Please check the AV1 and AV2 signal whether connected right or no. Rear view camera must connect to AV2 signal.
- Unclear image?
   Please check the camera whether has fog or others inside. And adjust the contrast of the monitor.
- 4. If any other question, please contact our customer service.