



User Manual FJL50

www.fujimedic.com

TABLE OF CONTENTS

• FUJIMEDIC INTRO	Contents	2 3
CHAIR	Components Massage Points	4 5 6 7
	Interface	




	Interface	
	Pre-Programed Massage	
	Demo	10 10
Е	Custom Massage	20-24
	Spot Massage	75 77
	Settings	28-33




Safety	
Grounding Instruction	
Product Cleaning	
Warranty	

DIMENSIONS


First, let's get your chair inside.





CONTENTS


Everything you need for a relaxing experience.




Move & Clearance

A few simple steps to find the best place for your new chair.

HOW TO MOVE




Move with a slight pull or push Caution: If you roll the chair on wood floor, marks may be left




Two people are needed to lift the chair

CLEARANCE




Reserve space on left and right



CHAIR COMPONENTS

Some of your chair's most important features.




Note: The speaker will only operate when the massage chair is in operation



To play music using your massage chair's speakers please connect your smartphone, tablet, or other electronic device to your chair using bluetooth.

MASSAGE POINTS



CHAIR SPECIFICATIONS

A few important facts about your massage chair.



Model No. FJL50



Max Massage Time 30 minutes



Dimensions (L x W x H) Chair dimension: 62.2" x 33.1" x 47.6" Reclined dimension: 77.2" x 33.1" x 41.3"



Shipping Weight Gross weight: 321.2lbs Net weight: 275lbs



Usage Condition Environment temperature: 10 °C-40 °C Contrasting humidity: 30-85RH



Storage Condition Storage temperature: -20 °C-60 °C Storage humidity level: 30-85RH



Power Consumption 200W



Power of Speakers 14W (2 sides)



Rated Voltage 110 - 120V



Length of Wiring Controller wiring 27.6" Power supply wiring 70.9"




Rated Frequency 60Hz




Safety Feature Equipped with overheating and power surge detectors safety feature

WIRED TOUCH-PAD INTERFACE


We have designed your massage chair's tablet controller with a user-friendly interface to make using your chair even easier.



Home Screen








PRE-PROGRAMED MASSAGE


We have designed your chair with multiple massage options for your changing needs. Follow these simple instructions to begin a new pre-programed massage.



Choose 1 of our 11 pre-programed massages (Gentle, Stretch, Joint Care, Spine Care, Relax, Vigourous, Swedish, Thai, Japanese, Chinese, Balinese)


Pre-Programed Massage Interface





Using the arrows, you can adjust the standard shoulder position

Adjust Massage Strength Interface




In this interface, you can adjust massage 4D strength, tapping speed, kneading strength and air intensity

Adjust Chair Angle Interface



Adjust your chair quickly by choosing one of the three preset seating positions. You can also press and hold the arrows to adjust parts of the chair independently


Change the Light Interface



Choose 1 of the 7 types of LED light patterns


DEMO

To give you a quick glimpse of what your chair can do, we have created a demo module.




Choose the "Demo" icon to begin demo program

Demo Interface



CUSTOM MASSAGE

Every body is different. That's why we've given you the option to customize your massage to meet your specific needs. Follow these simple instructions to create a new custom massage. You can create up to 3 custom programs. To delete a custom massage program, press and hold that icon and choose the "x".



Choose the "Create New" icon to begin creating your massage program



Select the areas you need massaged




Select which massage actions you would like. The knead, tap, clap, and shiatsu massages can be combined with swedish or roll




Choose the "Custom 1" icon to start your program

Custom Interface




SPOT MASSAGE

This is a fixed massage area and actions program.




Choose the "Spot Massage" button to take you to the Spot Massage page


Spot Massage Interface 1



Spot Massage Interface 2




SETTINGS





Choose the "Settings" button to take you to the settings page


Settings Interface




Trouble Shooting










Your chair is detecting possible malfunctions, please wait for the detection result




You can use your detection code when contacting the customer team about your chair's problems









IMPORTANT SAFETY INSTRUCTIONS (MUST BE FOLLOWED)

The safety instructions must be strictly followed in use to avoid personal injuries and property damage are as follows:


All the safety instructions are described in compliance with degrees of the injuries or damage as a result
of wrong use.

Warning	Actions tending to cause serious injuries or death
Actions tending to cause minor injuries or property damage	

· Pay attention to the symbols before safety instructions (an example is given below).

 \bigcirc Actions that must be absolutely forbidden

Actions that must be followed




M Warning Before using the massage chair or moving the backrest or the footrest, make sure there is no person or pet close to the chair (in front , behind , below or on the side). Before using the massage chair, make sure there is no foreign matter between the backrest and the back cover. Otherwise accidents or physical discomfort may happen. Before using the massage chair, lift the backrest pad and check whether the fabric of the traveling sections of the massage rollers or other positions are damaged. (Even if the fabric is slightly damaged, stop the product immediately, pull out the power plug, and call customer service.) If you use the product when the fabric is damaged, you may get injured or get an electric shock. Do not massage for more than 30 minutes each time. Do not massage a single part for more than 5 minutes. If any of these safety instructions are not followed, you may suffer an adverse effect and become injured. After use each time, turn the power switch to OFF position and disconnect the power plug. Otherwise accidents or injuries may happen. · Follow the regulations about use of the socket and the wiring devises. Use a 110~120V, 60HZ power supply. Don't use the product in a foreign country or connect it with a transformer without permission. Otherwise electric shocks, product faults or fires because of overheat may happen. · Insert the power plug thoroughly into the socket. Otherwise electric shocks or fires caused by overheat may happen. Remove dirt/dust from the power plug at regular intervals. Otherwise fires caused by poor insulation due to factors such as moisture may happen. (Wipe the power plug with dry cloth). In the case of any abnormality or fault, stop the product immediately and pull out the power plug to avoid smoke, fires and electric shocks. Abnormality and fault examples: (1) The product fails to work after the power switch is turned to the ON position. (2) After the power line is moved, the product is discontinuously powered on. (3) During use, the product gives off a burning smell or an abnormal sound. (4) The product is deformed or abnormally heating. In any of these abnormalities and faults, have the product inspected and repaired by an authorized service center immediately. If there is any foreign matter between backrest and main PCB box cover, stop the product, disconnect the power supply and take out the foreign matter by opening the protective fabric covering at the lower part of backrest. Otherwise product faults or personal injuries may happen.

Ω

Must be


followed





 If the product is used again for massage after a period of out-of-service, read the user manual again and make sure the product can run normally first.


Otherwise accidents or injuries may happen.



Caution

Product wetting forbidden.

• Do not sprinkle substances such as water on the product or its remote controller. Otherwise electric shocks, short circuit or product faults may happen.



Forbidden

• Before cleaning or maintaining the product, pull out the power plug first. Otherwise electric shocks or injuries may happen.

- In the case of a power failure, pull out the power plug at once.
 Otherwise accidents or injuries may happen when power is restored.
- When the product is not used, pull out the power plug.
 Otherwise electric leakage fires may happen because of insulation aging caused by dust and moisture.

GROUNDING INSTRUCTIONS


The product must be grounded to reduce the electric shock hazard because of functional faults of the product. The product has a power cord with a grounding conductor and a grounding plug. The grounding plug must be inserted into an appropriate socket that has been correctly installed and grounded in full compliance with the local code and decree.

A Caution

If the grounding conductor is not correctly connected, electric shocks may happen. If you are not sure about correctness of the grounding, have it inspected by a professional electrician. Even if the grounding plug provided with the product does not match with the socket you have, do not refit it by yourself but ask a professional electrician to install a appropriate socket.

The product has a grounding plug. Make sure the product is connected with a socket matching with shape of the grounding plug.

Do not connect the product to a multi-plug.



PRODUCT CLEANING

Wipe the synthetic leather with a soft dry cloth.

- Don't clean the product with chemicals such as thinner, gasoline and alcohol.
- When using a leather maintenance product (cleaning cloth) sold on the market, follow its directions for use.
- If the synthetic leather is very dirty, wipe it with the method below.
 ① Put a piece of soft cloth into water or 3% to 5% neutral detergent contained hot water and wring it out.
 ② Wipe surface of the synthetic leather with the soft cloth.
 ③ Wipe the detergent with a piece of cloth once soaked in clean water and wrung out.
 ④ Wipe with a piece of wrung soft cloth.
 ⑤ Allow the synthetic leather to air dry.
- If it is difficult to remove the stains on the synthetic leather, soak a piece of melamine foam bought from the market into a neutral detergent and use it wipe the product.
- Do not dry the surface with a hair drier.
- Surface of the synthetic leather may be dyed by fabric colors; therefore, be careful when wiping the
 product with denim or colored cloth.
- Keep these positions from long-time contact with plastics to avoid fading.
- Synthetic leather may discolor, so the position in contact with the hair dye used should be covered by a towel.

CONSUMER WARRANTY

The FJL50 massage chair has a three year in-home service warranty. The warranties are only valid in the 48 contiguous states. We do not provide a warranty for chairs sold to Alaska or Hawaii.

Consumers may contact the Fujimedic customer service department at 1-877-977-0656 between 9:00 am and 5:00 pm PST, Monday through Friday or email us at service@fujimedics.com for warranty or service issues.

The warranty period begins from the day of purchase; no allowance or extension is offered for delivery and/or installation.

The warranty only applies to FJL50 massage chair, any accessories or enhancements are not included.

The Fujimedic service department will make an appointment with the consumer before they arrange in-home service which is performed by authorized technician.

In certain situations, the warranty does not apply :

- A: Customer cannot provide receipt and warranty card.
- B: Damage caused by improper installation, abuse, or improper maintenance.
- C: Damage caused by disaster (ex. earthquake, fire, flood, etc.), abnormal power supply, breakages (ex. pets chewing, drink spilling, etc.).
- D: Massage chair repaired by unauthorized technician or if unauthorized modifications occur to the massage chair.

If the synthetic leather, fabric, sponge, or fillers become naturally worn, they are not considered as defect under this warranty. Read the safety instructions before using this massage chair. Under no circumstance shall Fujimedic or its representatives be liable for indirect, consequential, or incidental damages (including damages for lost profits, business interruption, bodily injury, and so on).

The warranties are not applicable if the massage chair is being utilized for business use.

861 S. Oak Park Road, Covina, CA 91724

TEL: 1-877-977-0656 FAX: 1-800-521-4712 SERVICE@FUJIMEDICS.COM