


Ninja Dragon Phantom X 4K Dual Camera Smart Quadcopter Drone




A. Connect the drone with the controller:

1. Please fully charge the battery before start
2. Press the power on / off button on the drone to turn the power on




3. Press the power on / off button on the controller to turn the power on. Red light on the right will keep flashing, the drone is on a paring mode
4. Push the left hand joystick up , then push it down
5. You will hear a “beep” sound twice, it means controller paring is completed and the red light becomes solid



6. Now your drone is connected with the controller

B. **Connect the drone with your phone for pictures and videos:**

1. Please turn off the drone and the controller if you paired the drone with the controller earlier.
2. Turn on the drone
3. download the app from App Store or Google Play and install it



4. Turn on the wifi from your mobile phone and do a quick scan
5. Select **“WIFI_FPV_XXX”** and connect or any other available network for your drone
6. Open the app and tap **“START”** on the top right hand corner



7. The following is the layout of the function keys on your screen and now you are ready to go!

