

《Switch Plates》 Installation Instructions

Please be sure to read these instructions thoroughly before installing this product.

Before Installation

- There are many dangers that may occur when installing this product. We therefore strongly recommend requesting a professional contractor install the product.
*Be sure to give the included instruction manual to the customer after installation.
*This product must be installed by a qualified electrician.
- Be sure to read the installation instructions thoroughly before starting the work to ensure correct installation.
- Check the parts list to ensure that all necessary parts are included in the packaging.
- Be sure to use the specified measurements.
- Items such as embedded switch box, insulation caps and crimped terminals must be prepared separately wherever necessary.

Precautions for Installation

- Be sure to consider safety first when installing the product.
- Follow the steps in the installation manual in the correct order. The strength or functionality of the product may be reduced.
- Use the genuine screws provided with the product in the correct quantity, and tighten them securely to fix the product in place.
- Do not modify the product.
- Do not use this product if the screws are loose. Doing so may result in damage to the product or cause a serious accident.
- After completing installation, check that all screws are tightly secured.

Parts List

- Switch Plate×1
- Toggle Switch (installed)
- Knob Cover (installed)
- Nut Cover (installed)
- Pedestal Screws
Round/Square/Hexagonal/0712×3 (M4×35)
1112×5 (M4×35)
1612×7 (M4×35)
*1 of each type of screw is provided as a spare
- Installation Instructions×1
- Instruction Manual×1

Installing the Switch Plates

- (1) Attach crimped terminals (not provided) to the wires.
- (2) Attach the terminals to the toggle switches.
*Check that the nut covers on the front and nuts on the back are not loose. When installing the product, be careful not to drop the switch plate.
- (3) Fix the embedded box (not provided) in place using the installation screws from the front of the switch plate.
*Be careful not to damage or scratch the product using the tip of a screwdriver.
- (4) Check that there is no looseness in the screws on the face side, and check the movement of each of the toggle switches.



MATUREWARE

by FUTAGAMI

1000 Chokeiji, Takaoka-shi, Toyama, 933-0951, Japan
Tel. 0766-23-8531 Fax. 0766-26-5614
www.matureware.jp