



Instruction Sheet

Please FULLY CHARGE Before First Use!

1) Press button on bullet to activate. Light will illuminate when powered on.


2) Press Top Button on Remote to turn on. Use this button to increase thru 4-speeds of power.

3) Use Middle Button to operate each of the 15 built in functions.

4) Use Bottom Button to decrease speeds.

5) Press Bottom Button 4 times to shut down the remote.

6) Press and Hold Button on Bullet for 3 seconds to Power Off and conserve battery life.



Antenna

nü
Sensuelle



Bottom
Of Bullet

USE STEP 6
to Power Off
Bullet



1-YEAR WARRANTY

Visit us at
nusensuelle.com
to register your NU
Sensuelle Product!

Charge The REMOTE CONTROL

Insert pin from USB Cord as shown into charging jack on bottom of remote and plug into USB Wall Charger or Computer USB Port.

Light will flash when the Remote is charging. The Remote is fully charged when the light stops flashing!

Charge The BULLET

Attach Magnetic Charge Cable to the pin connectors on the bullet and plug into USB Wall Charger or Computer USB Port.

Light will flash when the Bullet is charging. The Bullet is fully charged when the light stops flashing!

