



1	12831000A06028	Refrigerator door assembly	26	12131000001673	Mounting box assembly
1.1	12131000010476	Door gasket assembly of refrigerator	27	17431000000281	Power cord
1.2	12231000007247	Stopper	28	12131000004317	Drain tray
2	17131000000026	Display control panel	29	11101010012275	Fixed speed reciprocating compressor
3	12131000000445	Display control panel mounting box	29.1	12031000001561	Starter
4	12131000001064	Box cover	29.2	12031000001316	Protector
5	12231000007048	Upper hinge assembly	29.3	12031000001171	Electric appliance shield
6	15733000000009	Refrigerator roll bond evaporator	30	12931000000647	Compressor back cover
7	12131000000877	Locking buckle	31	12231000005846	Compressor mounting panel assembly
8	12931000000074	steel wire shelf of the refrigerator	32	12931000000685	Universal wheel
9	12231000006457	Fixed base	34	12231000007166	Upper hinge assembly
10	12231000007178	Beer barrel base pad	106	12631000000188	Spout plug
11	12231000006867	Lower hinge adjust feet assembly			
12	12931000000687	Universal wheel			
13	12131000000999	Levelling feet			
14	12131000004291	Drain tray assembly			
15	12131000033582	top cover assembly			
15.1	12131000000876	Locking buckle			
16	12931000000189	Guard bar of top cover			
17	12831000004750	Cabinet assembly			
19	12631000000187	Hole cap			
23	11002015001682	fan motor			
24	12131000001191	Plastic cover			
25	17131000000140	Main control board			