


# INSTRUCTIONS FOR THE SLIP-IN EASEL


NOTE: These images show the 9x12 Slip-In Easel in the 9x12 Guerrilla Box™. The directions here apply to all sizes of Slip-In Easels and their corresponding pochade boxes.



The Slip-In Easel will add flexibility to your Guerrilla Painter™ Pochade Box. With it you can:

- Position panels up and out from the box lid.
- Hold panels larger or smaller than your box size while you're painting.

If you are using your Slip-In Easel with the 9x12 Guerrilla Box™ we suggest that you use the Panel Clips that came with your box. This will allow you to keep the Slip-In Easel in the front of the lid, while allowing you to store panels in the slot behind.



The Slip-In Easel comes with two aluminum rods that slide into the corrugations (A). The aluminum rods are held in place by friction. If you find that the rods slide too hard (or too easy), you can adjust this easily with a pair of pliers, as show (B).

The Slip-In Easel can be used in two different orientations. With the shelf in the lower position (C), larger panels can be accommodated. Rotate the Slip-In Easel 180° to use in the upper position (D) when working with smaller panels.

