

Songs Welcome To OnSong



to get started with OnSong, tap "Songs"
you can use this to manage your music
don't forget you can swipe left to right
and simply delete songs you don't like

Verse 2:

tap the gear icon all the way to the right
and get help on any topic you need
or tap the sliders icon almost to the right
and change how your song looks

Verse 3:

try out the other menubar options
and see all that you can do
like editing and playing songs
or sharing music with your band

Verse 4:

to navigate, just swipe or tap
left or right or up or down
scroll anywhere you want to go
tap in the middle for full screen

Bridge:

Now you can use line formatting to...


bold a line of lyrics

or italicize it

or do both

or make it red

even highlight it in yellow



Click settings/gear icon



Close

Utilities



Backup

Backup your library for safekeeping



Getting Started

Videos, user manual and support



Communicate

Give feedback and get support



Editors

Change settings and data



Add-Ons

Purchase add-ons and media



Console

Manage your songs on your computer



select settings

Settings

Change settings to your liking



Tools

Perform advanced functions



[Done](#)

Settings



Foot Pedals

Setup foot pedal actions to control your sets.



Song Editor

Change the default functionality of the song editor.



Sticky Notes

Configure default options for new sticky notes.



Style Preferences

Configure default font settings and styles.



Song Reporting

Change how songs are tracked and reported.



Use Dark Menus in Low Light Mode



MIDI SETTINGS

MIDI Settings

Configure sources, destinations and features.



[Back](#)

Foot Pedals

[Done](#)ACTIONS **Set pedal functions as follows:**Pedal 1 [Scroll Up](#) >Pedal 2 [Previous Song](#) >Pedal 3 [Scroll Down](#) >Pedal 4 [Next Song](#) >**then scroll down...**

SCROLLING BEHAVIOR

[Scrolling Behavior](#) >Disable Section Navigation Disable Set Navigation

Sections available in text-based formats

Pages only available in text and PDF files

TRIGGERS

Back

Foot Pedals

Done

Disable Section Navigation



Disable Set Navigation



Sections available in text-based formats
Pages only available in text and PDF files

TRIGGERS

Forward Pedal Trigger

None >

Start Set Trigger

None >

Finish Set Trigger

None >

OPTIONS

Pedal Setup >

Show Icon In Menubar



Back

Pedal Setup

Done

PEDAL SETUP

Pedal Type

iOS Compatible >

Pedal 1

**change pedal type to
iOS Compatible**

Pedal 2

Pedal 3

Pedal 4

Pedal 5

Pedal 6

Pedal 7

Pedal 8

Enter the text that will trigger each pedal for
keyboard-based foot switches