




## SON OF STALKER ASSEMBLY INSTRUCTIONS



Your Son of Stalker comes ready to hunt out of the box. There is no assembly required. Use only Sillosocks Flappers with your Son of Stalker. See pictures for proper use. Use the fiberglass stakes that come with your Sillosocks Flappers. If you have the two piece stakes you might want to super glue the two sections together so they do not slip during use.

BE CAREFUL WHEN HOOKING YOU MACHINE TO THE 12 VOLT BATTERY. IF YOU REVERSE POLARITY IT WILL RENDER YOUR SPEED CONTROL USELESS.



Attach the flyer. You can bend the wire in the nosepiece of the flyer to get the correct angle of the decoy.

Adjust the speed control to the desired speed.

A light coat of camouflage paint will help with concealment of your unit during hunting. Krylon Flat Khaki works perfect.

Use the provided ground stakes for use during high winds.

