

# urban ambiance


Installation Instructions: UHP3914

PART	DESCRIPTION	QUANTITY
Α	Fixture	1
В	Stem	1
С	Metal frame	1





# HARDWARE CONTENTS (not actual size)





# Safety Information

Please read and understand this entire manual before attempting to assemble, operate or install the product.

CAUTION: Read instructions carefully and turn electricity off at main circuit breaker panel before beginning installation.

CAUTION: Risk of fire. Min. 90°C supply conductors. Consult a qualified electrician to ensure correct branch circuit conductor.

WARNING: If any Special Control Devices are used with this fixture, follow instructions carefully to assure full compliance with N.E.C. requirements. If there are any questions, contact a qualified electrical contractor.

CAUTION: All glass is fragile. Use care when handling glass shades and bulbs.


## Preparation


- 1. Before beginning installation, make sure all parts are included using the contents diagrams from page 1. If any part is missing or damaged, do not attempt to assemble, install or operate the product.
- 2. Estimated assembly time: 30 minutes.
- 3. Tools required for assembly (not included): Phillips screwdriver, pliers, wire stripper, safety glasses, electrical tape, ladder.

#### Care and Maintenance

Shut off main power supply before cleaning product or changing light bulbs. To clean, wipe with damp cloth. Do not use abrasive cleaners or cleaners that contain alcohol.


## **Assembly Instructions**






- 1. Install the chain holder (EE) onto the nipple (FF). Next, loosely thread the hex nuts (AA) onto the nipple (FF) and then thread this assembly onto the mounting strap (CC). Install this assembly to the outlet box using the mounting screws supplied with the outlet box (not included).
- 2. In this step, you will adjust the depth of the chain holder in relation to the canopy depth.


Take the canopy (MM) and slip it over the chain holder (EE). You will need to adjust the chain holder so at least 1/4" of the threaded portion is exposed through the canopy hole. This is done by adjusting the depth of the nipple (FF) on the mounting strap (CC). When the chain holder (EE) is correctly adjusted, remove the canopy (MM) and tighten the top hex nut (AA) against the mounting strap (CC) and the bottom hex nut (AA) against the chain holder (EE).



#### **ASSEMBLY INSTRUCTIONS**



4. Attach fixture (A) to the metal frame (C) and use the stem (B) to secure it tightly.



NOTE: During this step, determine the hanging length of your fixture by adding or removing pipes and chain links. The electrical and ground wire may also optionally be cut to length.


Do NOT cut electrical or ground wires until this length is determined. Leave AT LEAST 6 inches MINIMUM of wire past the chain holder (EE) to allow for easy connections in step 6.

(Chain links can be spread open with 2 pairs of pliers. Twist the split link ends in opposite directions and close by squeezing them back together.)


5. Once hanging length is determined, pass wires through pipe (JJ), pipe (KK) and nipples (LL), tightening pipes to assembly as you go to avoid twisting the wires. Pass wires through chain loop (HH) and tighten chain loop (HH) to pipes assembly (JJ).

Open chain length at each end of chain. Attach one end of the chain (GG) to the loop (HH) on top of the pipes assembly (JJ) and the other end of chain (GG) to the chain holder (EE). Continue to weave the wires through the chain links (GG). continue to pass the wires and the chain through the screw collar (DD) and canopy (MM).


#### **ASSEMBLY INSTRUCTIONS**



6. Strip 3/8" of insulation from the electrical wire ends. Using wire nuts (BB), connect the RIBBED fixture wire to the WHITE supply wire from the outlet box; connect the SMOOTH fixture wire to the BLACK supply wire. Connect the fixture ground wire and supply ground wire using a wire nut or by fastening to the ground screw on the mounting strap. Push all wire connections into the outlet box.



7. Tuck the wires into the outlet box and slip the canopy (MM) over the chain holder. Thread the screw collar (DD) onto the chain holder to secure the canopy tightly to the ceiling.



8. Thread the lamps (not included) into the fixture sockets. Use 60-watt MAX incandescent medium base lamp, SBCFL or SBLED.