# urban ambiance

PART DESCRIPTION QUANTITY   A Fixture 1   Image: Second colspan="2">Image: Second colspan="2" Image: Second colspa="2" Image: Second cols								
HARDWARE CONTENTS (not actual size)	PART	DESCRIPTION	QUA	ANTITY				
(HH) = 20  (H)  (20)  (H)	Α	Fixture		1				
(HH) = 20  (H)  (20)  (H)				7				
			()		_			
		A) (BB)			GG	(нн)		
Nipple Wire nut Mounting strap Hex nut Finial Lock washer					0	0		
(1/8IP) (1/8IP) (1/8IP) (1/8IP)	Nij (1/	pple Wire nut /8IP)	Mounting strap (1/8IP)			Lock washer (1/8IP)		
Qty:1 Qty:3 Qty:1 Qty:1 Qty:1 Qty:1	Q	ty:1 Qty:3	Qty:1	Qty:1	Qty:1	Qty:1		



#### **Questions?**

Call our Customer Care Team at 1-855-303-4229

www.urbanambiance.com

## Safety Information

Please read and understand this entire manual before attempting to assemble, operate or install the product.

CAUTION: Read instructions carefully and turn electricity off at main circuit breaker panel before beginning installation.

CAUTION: Risk of fire. Min. 90°C supply conductors. Consult a qualified electrician to ensure correct branch circuit conductor.

WARNING: If any Special Control Devices are used with this fixture, follow instructions carefully to assure full compliance with N.E.C. requirements. If there are any questions, contact a qualified electrical contractor.

CAUTION: All glass is fragile. Use care when handling glass shades and bulbs.

#### Preparation

1. Before beginning installation, make sure all parts are included using the contents diagrams from page 1. If any part is missing or damaged, do not attempt to assemble, install or operate the product.

- 2. Estimated assembly time: 30 minutes.
- 3. Tools required for assembly (not included): Phillips screwdriver, pliers, wire stripper, safety glasses, electrical tape, ladder.


#### Care and Maintenance

Shut off main power supply before cleaning product or changing light bulbs. To clean, wipe with damp cloth. Do not use abrasive cleaners or cleaners that contain alcohol.

### Assembly Instructions

1	1. Screw nipple (AA), Lock washer (HH) and hex nut (DD) onto mounting strap (CC) Hardware Used				
	(AA) Nipple		X1		
	DD Hex nut		X1		
	CC Mounting strap		X1		
	(HH) Lock washer	Ø	X1		
2	2. Attach assembled parts from 5 mounting screws supplied with t (not included).		the		

## **Assembly Instructions**





urban ambiance

www.urbanambiance.com