



20V Fast Battery Charger

Instruction Manual

*We've tried to make this manual useful, simple, and understandable.
Please read it carefully, and keep it safe for future reference.*



WHAT'S INSIDE THIS MANUAL

THE ABC'S OF FAST CHARGER SAFETY	3
Safety symbol meanings	4
TECHNICAL SPECIFICATIONS	6
HOW TO USE THE NOCRY FAST CHARGER	6
How to remove or insert a battery	6
How to wall-mount the fast charger	7
MAINTENANCE	8
How to clean your fast charger	8
FAST CHARGER LIABILITY	9
RESPONSIBLE DISPOSAL	9
WARRANTY	10
HOW TO CONTACT NOCRY	11

THE ABC'S OF FAST CHARGER SAFETY

Read all safety warnings and instructions *before* using your fast charger. They're pretty reasonable, and neglecting them may result in electric shock, fire, and/or serious injury. There are other (and much better) ways to get your adrenaline going.

Save this manual for future reference, review in between uses, and make sure that anyone who's going to test your new fast charger has read and fully understood all the information in here as well.

In case this manual disappears into the black hole that all manuals seem to fall into, you can get a digital version of it at <https://nocry.com/pages/instructions>, or by letting us know at wecare@nocry.com.

So, let's get to it, shall we?

- ✓ **Only use original NoCry 20V batteries with your fast charger for powering all NoCry cordless power tools.** Use of unoriginal batteries of the wrong voltage or unapproved fast chargers may lead to explosions. And who needs that?
- ✓ Your fast charger is designed to **charge your batteries indoors only and away from living areas.** Ideally batteries should be charged on a bench in a workshop or garage. If you do not have such a space, charge your batteries away from people in an area of infrequent use, just in case anything should happen. Better safe than sorry.
- ✓ **Your fast charger isn't waterproof or splash proof.** Under no circumstances should you use it in damp or wet conditions, rain, spray with water, or immerse in liquid, or risk the danger of explosion or electrocution. Zap.
- ✓ **Keep your fast charger away from open flames, sparks, fuel lines or any other ignition sources,** or combustible materials.

- ✓ **Do not use the charger if it has been subjected to a heavy knock, dropped** or otherwise damaged in any way. Take the charger to an authorized service centre to be checked out or repaired or contact us at wecare@nocry.com, and we'll sort it out ASAP
- ✓ **Do not charge batteries in air temperatures below 40°F or above 105°F.**
- ✓ When charging multiple batteries, **always allow the charger to cool down before charging another battery.**
- ✓ There is **no need to open the fast charger** itself, so don't bother. You risk the danger of it short-circuiting and being electrocuted and it will also void your warranty, *really* not worth it.
- ✓ **Do not abuse the cord of the fast charger.** Never use it for carrying or pulling anything or forcefully disconnect it. Keep the cord away from heat, oil, sharp edges or moving parts. Damaged or entangled cords increase the risk of accident and electric shock.

NB! NoCry Work & Safety Gear and the manufacturing plant shall not be liable for any changes made to the tool, nor for any damage resulting from such changes.

Safety symbol meanings

These symbols are on your fast charger for a reason - to keep you aware and safe. Please take them into account.



This fast charger conforms with North American safety standards.



Read the instructions before starting to use this fast charger.



Do not throw this fast charger out with regular waste, but dispose of it in the appropriate manner so it can be recycled. See page 9 for how to dispose you fast charger responsibly.



This fast charger is intended for indoor use only.



Exercise overall caution when operating your fast charger.



This fast charger has a thermal fuse rating of 266 °F. Fuse will blow should this temperature be exceeded.



This fast charger is Class II (double insulated).



Fast charger has a max operating temperature of 122 °F. This operating temperature should not be exceeded.

TECHNICAL SPECIFICATIONS

Model	NoCry NBC-20V
Charging Voltage	120V, 60 Hz
Rated voltage	20V
Fast charger charger speed	2 Ah per hour
Battery charging time	1.5 Ah 45 minutes, 3 Ah 1.5 hours, 4Ah 2 hours
Total weight	0.80lbs

HOW TO USE THE NOCRY FAST CHARGER

How to remove or insert a battery

To insert a battery...

- ✓ Connect the charger to appropriate power outlet **before** inserting battery.
- ✓ Insert the battery pack by sliding the battery into the charger cradle, ensuring the contacts meet and make a 'click' noise.
- ✓ The red light will be continuously lit indicating that the charging process has started and is in progress.

- ✓ The green light will indicate that the charging of the battery is complete, the battery pack may be removed at this point or safely left in the charger.

To remove the battery, press and hold the unlock button on the battery and gently slide it away from the charger cradle.

NB! To ensure maximum performance and life of lithium-ion battery packs, charge the battery fully before first use. Batteries can be left in the charger cradle indefinitely without damaging the battery. The charger will keep with battery fresh and fully charged. Ready for when you need it.

How to wall-mount the fast charger

The fast charger can be wall-mounted in your garage, workshop or home or comfortably sit upright on a table or work surface.

To wall mount...

- ✓ Locate an electrical power outlet within reach of the fast charger, and away from a corner or other obstructions, which may affect air flow.
- ✓ Use the back of the charger as a template for the location of the mounting screws on the wall.
- ✓ Mount the charger securely using drywall screws (sold separately) at least 1" long, with a screw head diameter of 0.28–0.35".
- ✓ Be sure to leave a gap of at least 2" between the mounting wall and the surface under, so that the batteries can be inserted and removed without obstruction.
- ✓ Align the mounting slots on the back of the charger with the screws, fully engaging them with the slots. Job done.

MAINTENANCE

Good news - there are no parts inside your fast charger that require professional maintenance. All that's needed is some good old fashioned TLC - love your power tools and they will love you back.

For safety reasons and your overall peace of mind, we recommend having your fast charger given a once-over by an expert once every 12 months to ensure that it will continue to operate safely. We must mention that all (potentially deviating) national inspection and maintenance regulations must be observed.

How to clean your fast charger

Before starting to clean your fast charger, **disconnect it from the power outlet.** For the most part, you'll face the issue of dust in or around power contacts.

- ✓ **To clean** - wipe down the power cable, charger cradle and power contacts with a soft dry cloth or use compressed dry air at low pressure to remove any lodged debris or dirt.

NB! Do not use cleaning agents or solvents, as they may damage the plastic parts. In between cleanings, keep your fast charger away from dirt, dust and water as much as possible. Never use water or chemical cleaners to clean your fast charger.

FAST CHARGER LIABILITY

This product is covered by an EU directive, valid since 01.01.1990, specifying that the manufacturer is only liable for products if all the parts originate from the manufacturer or are approved by them, and if the units are mounted and operated properly.

If accessories or spare parts from third parties are used, liability can be partially or completely inapplicable. So no using those shifty parts you picked up on the cheap. In extreme cases the responsible authorities can prohibit the use of the entire unit.

We recommend you always buy original parts and accessories as compliance with all safety regulations is guaranteed, meaning you are covered and protected. Another weight off your mind.

RESPONSIBLE DISPOSAL

This product has been marked with a symbol relating to removing electric and electronic waste.

The Waste Electrical & Electronic Equipment Regulations (WEEE) requires that any product showing this marking must not be disposed of with other household or commercial waste. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate any such product from other waste types and recycle it responsibly at your local facilities. Check with your local authority, recycling centre or retailer for recycling advice. Don't just chuck it in the trash or leave out on the street.

WARRANTY

All NoCry products are inspected and tested to ensure their quality before leaving the factory. If you're not happy with your NoCry product, please contact us within 30 days of receiving it at wecare@nocry.com to return it for free for a replacement product or to receive a full refund. The choice is yours.

Each NoCry electric product is warranted to be free of defects in material and workmanship for the period of FOUR years from the date of original purchase. Warranty does not cover normal wear and tear, abuse, altered products, modifications, and products that have been repaired or attempted to be repaired by others than NoCry. At NoCry's discretion, a defective product will be repaired or replaced.

This warranty gives you specific legal rights, but may be superseded by any other rights or warranties in effect, which may vary from state to state (or based on your local jurisdiction). If you think you might have a defective product, please contact us at wecare@nocry.com. Our customer care team will be happy to help and start the (free) procedure to determine whether your product is defective.

NoCry's warranty applies to ONLY products being sold by Authorized Resellers. We regretfully will not provide any warranty for products sold by any other sources. Proof of purchase will be required to obtain warranty. Please review the warranty carefully, and contact us if you have any questions.

HOW TO CONTACT NOCRY

We're glad to have you join the NoCry community, and we hope you are happy with your new NoCry Fast Charger. If you have any questions or concerns, let us know by emailing wecare@nocry.com

We'd also love to connect with you via social media. You can find us on Instagram, Facebook and Pinterest by searching "NoCry Work & Safety Gear".

Thumbs up or thumbs down for your experience with your NoCry Fast Charger?



If this is your response, know that at NoCry, we try to treat everyone like we'd treat our own mom. On her birthday, no less. So **please let us know what went wrong by sending us an email at wecare@nocry.com**. We'll be on the case right away.



If you're happy with your purchase, why not spread the word to others who are looking for a fast charger AND **help us serve you better and grow as a company**, by leaving a review on Amazon? To leave a review, go to Amazon > Orders (top menu) > Write a product review. Or search for the NoCry Fast Charger on Amazon, and leave your review that way.