

## Because keeping you safe is our top priority...

## Please take a moment to read through the following care and use instructions for your new apron.

We care a lot about your safety and satisfaction. That's why we've put together a few precautions for you to follow while using your NoCry Work Apron.

• The NoCry work apron is tear and abrasion resistant, but not cut or puncture resistant. Make sure you don't place any sharp objects into the apron pockets without appropriate safety covers.

• Use the buckle clip to put the apron on and take it off. The best way to adjust the apron is to first adjust the height and then the width. After finding the most comfortable position for the belt strap, adjust the height again until you feel a very light pressure from the shoulder straps. The apron should feel nice and snug around your body.

• If you're going to carry heavier tools in the apron pockets make sure that the shoulder paddings remain on your shoulders after you have adjusted it. If needed, readjust it.

• Do not overburden yourself with too many heavy tools in the apron at once. Make sure to watch your posture while working so that you do not overstrain your back.

• You can remove minor dirt/stains from your work apron by using a soft brush. If the dirt/stains are stubborn use a washcloth and lukewarm water with neutral detergent solution to clean it.

• Do not machine wash or use hot water to clean the apron. Avoid bleach (chlorine or peroxide) as this will discolor and damage the fabrics, edge binding and sewing thread. Avoid the use of alcohol or alcohol based products. Do not machine dry or iron the apron. After cleaning, hang it to drip dry.

If you have any questions or concerns about your work apron, feel free to contact our customer support at wecare@nocry.com. We're always here to help.

## Love your new NoCry work apron? Share an honest review of your experience on amazon

Your feedback will go a long way in helping us serve you better and grow as a company.

To Leave an Amazon Review go to **Amazon > Orders (top menu) > Write a product review** Or, search for NoCry Apron on Amazon, and leave a review