



Because keeping you safe is our top priority...

Please take a moment to read through the following care and use instructions for your new eyewear case.

We care a lot about your safety and satisfaction. That's why we've put together a few precautions for you to follow while using your NoCry Eyewear Case.

- The case has a structure which won't give in to accidental drops and light to moderate pressure, but do make sure not to place the case under or between heavy objects that could crush it and damage the glasses inside.
- The main purpose of this case is to offer a safe place for you to store and carry your safety eyewear, so we have designed it to be lightweight and easy to carry around. It's not designed to offer heavy-duty protection in extreme circumstances.
- This case is designed to store and protect NoCry Safety Glasses. We are not able to guarantee that other models from other manufacturers will fit into the case. When placing your glasses into the case make sure that you're able to close the case without issues. If the case doesn't fit your glasses please contact us at wecare@nocry.com.
- The case should not be exposed to high temperatures for an extended period of time. When possible, avoid making it wet. By taking care of your case it will stay good looking, firm, and protective for longer.
- You can eliminate minor dirt/stains from your NoCry case through brushing. Avoid washing the case with cleaning agents containing medium or strong solvents. Never clean it in a washing machine.

If the case is not a great fit for your glasses or you have any questions or concerns about it, feel free to contact our customer support at wecare@nocry.com. We're always here to help.