









Printing Instructions;

Ensure that your printer page size is set to A4 and the scaling is set to 100% or "actual size" on your print dialog box.

After printing check with a ruler to ensure it matches the scaling of the ruler below.

Your foot should comfortably fit within the inner dotted line, which represents the stitching footprint.







Printing Instructions;

Ensure that your printer page size is set to A4 and the scaling is set to 100% or "actual size" on your print dialog box.

After printing check with a ruler to ensure it matches the scaling of the ruler below.

Your foot should comfortably fit within the inner dotted line, which represents the stitching footprint.






30



Printing Instructions;

Ensure that your printer page size is set to A4 and the scaling is set to 100% or "actual size" on your print dialog box.

After printing check with a ruler to ensure it matches the scaling of the ruler below.

Your foot should comfortably fit within the inner dotted line, which represents the stitching footprint.






31


Printing Instructions;

Ensure that your printer page size is set to A4 and the scaling is set to 100% or "actual size" on your print dialog box.

After printing check with a ruler to ensure it matches the scaling of the ruler below.

Your foot should comfortably fit within the inner dotted line, which represents the stitching footprint.






32


Printing Instructions;

Ensure that your printer page size is set to A4 and the scaling is set to 100% or "actual size" on your print dialog box.

After printing check with a ruler to ensure it matches the scaling of the ruler below.

Your foot should comfortably fit within the inner dotted line, which represents the stitching footprint.






33


Printing Instructions;

Ensure that your printer page size is set to A4 and the scaling is set to 100% or "actual size" on your print dialog box.

After printing check with a ruler to ensure it matches the scaling of the ruler below.

Your foot should comfortably fit within the inner dotted line, which represents the stitching footprint.





Printing Instructions;

Ensure that your printer page size is set to A4 and the scaling is set to 100% or "actual size" on your print dialog box.

After printing check with a ruler to ensure it matches the scaling of the ruler below.

Your foot should comfortably fit within the inner dotted line, which represents the stitching footprint.

