

WARNING

CHOKING HAZARD

Small parts can be swallowed and block the airway. Do not allow children under the age of 3 to use this product.


Use under adult supervision at all times.

FIRE HAZARD

Keep all flame and heat sources away from tent fabric.

Assembly and usage guidelines:

- Adult assembly required
- Adult supervision required at all times
- Ages 3+



Pole A -24 Pcs



Pole B -24 Pcs



Pole Sleeve -6 Pcs



Cotton Cover



Rope -6 Pcs




Connector Tubes -24 Pcs



Connector Tubes -6 Pcs







Connector Tubes -6 Pcs



Connector Tubes


⚠ Please tightly insert the rods into the connectors, or the fabric cover might not fit.






x 12

4 Use connector tube **1** to connect two poles **B** together, a total of 12 groups.



x 6

5 Follow the picture to connect poles assembled in step 4 with the longest end of connector **2**.



6 Follow the picture to vertically insert the poles assembled in step 5 on the frame bottom.

