
## Cream Gazebo With Side Panels 2.7x2.7M

Simple Assembly Instructions -Please keep for future reference

650/2777



#### Dimensions

Width - 270cm Depth - 270cm Height - 250cm

### Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customer Helpline:  $08456\,400\,800$ 

## **MPORTANT SAFETY INSTRUCTIONS**

## Read all instruction before using and keep for future reference

- Read these instructions carefully and familiarise yourself with the procedure before assembling the unit.
- Check that you have all the component parts following the list on the page 3 and familiarise yourself with each part before proceeding.
- · Take all the fittings out of the plastic bag and separate them into their groups.
- Ensure you have enough space to lay out all the parts after using. before assembly.
- . To avoid scratching it is recommended that you assemble the unit on a soft level surface.

- Please keep children away when assembly. Please keep children under direct supervision of adult when using.
- Please do not use the gazebo under windy condition.
- Always use guy rope and pegs to secure the gazebo when using.
- This Gazebo is not water proof, but is shower proof.
- This Gazebo is not a permanent structure and should be disassembled and stored away

- Do not repack your Gazebo until completely dry.
- We recommend assembly by two persons under light or no wind conditions.
- This Gazebo must not be left erect in windy conditions.
- Keep the Gazebo Fabric away from screws, nails, staples, hooks, etc to avoid damage to the fabric and frame.

### **A** CAUTION

#### Fire Precautions

- Do not place the Gazebo near lights, fireplaces, gas or electric heaters, candles, radiators, or any other sources of heat, fire or flammable liquids.
- This Gazebo features a Fabric cover that is not flame retardant.
- we recommend caution and common sense when in use
- This Gazebo can burning.
- Do not use naked flames in or around the Gazebo. We recommend you advise no smoking while inside.

#### Safety

 To avoid any risks of suffocation to animals or children dispose of the plastic bags immediately.

#### Cleaning

 As with all surfaces clean with a damp cloth and mild detergent, do not use bleach or abrasive products.  This Gazebo has no flame retardant cooking area and should not be use to house BBQs or other cooking methods.

## Components-Parts

If you have damaged or missing components, call the customer Helpline:08456 400 800

4xBase Plate

♠ 1xCenter Connector


4xCorner Joint

#### Please check you have all the parts listed below

A 1xGazebo Cover



1xpanel w/window



1xpanel w/o window



1) 8 x Top Pole (Φ19x565mm)



2 8 x Support Pole (Ф19x810mm)

2A4 x Support Pole (Φ19x810mm)

3 4 x Leg Pole (Ф19х688mm)

3A)4 x Leg Pole (Φ19x688mm)

4 x Leg Pole (Φ19x688mm)

0 0 0

## Components - Fittings

#### Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

**€** 8xPeg

4xGuy Rope



10xCurtain Ring




## Stage 1 - Fitting the Support Poles

### Step 1

Insert Support Poles (2) into the Support Poles (2). Ensure all the poles are fully inserted and secure. See fig. 1.


IMPORTANT: Because of the size of this unit we recommend that it is built in the place intended for using

NOTE:Locate the unit on flat Ground free from obstruction,in a sheltered area away from wind and heavy rain as this will damage the unit.



### Step 2


Use Corner Joints (F) to connect the Support Poles. Ensure all the poles are fully inserted and secure.
See fig. 2.



## Stage 2 - Fitting the Top Poles

## Step 3


Insert Top Poles (A) into the Top Poles (1). Ensure all the poles are fully inserted and secure.
See fig. 3.



## Step 4

Connect the Top Poles to Corner Joints (F) and Centre Connector (E). See fig.4.

NOTE: It would be useful to ask someone to help you at this step.



## Stage 3 - Fitting the Gazebo

### Step 5


Insert Leg Poles ③ into the unit. Ensure all the poles are fully inserted and secure.
See fig. 5.


NOTE: It would be useful to ask someone to help you at this step.



Carefully place the Gazebo Cover & over the assembled roof. Then pull the Gazebo tightly over the assembled roof frame. See fig 6.

NOTE: It would be useful to ask someone to help you at this step.





## Stage 4 - Fitting the Legs

### Step 7


Insert the Plate ① into the Leg Pole ③ Connected to the Leg Pole ④ Then insert the whole Connected Leg Poles into the unit. Ensure all the poles are fully inserted and secure. See fig 7.


NOTE: It would be useful to ask someone to help you at this step.

### Step 8

Use the Velcro Tapes inside the Gazebo Cover to fix it onto the assembled Frame.
See fig 8 & 9.

Attach the Gazebo Cover's Hooks into holes on the Leg Poles (a). Tighten by moving the Hook to a lower hole. See fig. 10.





## Stage 5 - Fitting the Guy Ropes

### Step 9

Attach the end of the Guy Rope (h) to the corner of the top cover ring on the Gazebo. Then attach one end to the Peg and drive the Peg into the ground.


See fig 11, 12 & 13.

Use the Same method as fig 14 to fix the other Guy Ropes.

The length of Guy Ropes can be adjusted. See fig 14.

NOTE: The pegs are for location purposes only. They will not support the unit in high winds, see above instructions.

NOTE: It would be useful to ask someone to help you at this step.



## Stage 6 - Finishing the Unit

### Step 10

CAUTION:Do not assemble or disassemble during strong winds.


Hang on all 6 pcs Panels @and©at the top using the Curtain Ring, ① velcro tapes at side of panels can be fastened to the Gazebo legs, Side Panels can be taken off separately. See fig 15, 16 & 17.

Assemble is complete.

NOTE: It would be useful to ask someone to help you at this step.



Always use this product with caution and read the important safety instructions.



If you need help or have damaged or missing parts, call the Customer Helpline: 08456 400 800 Retailer: Argos LTD

Address: 489-499 Avebury Boulevard Saxon Gate West Central Milton Keynes Bucks, MK9 2NW