


# 4x3M Waterproof Gazebo With 2 side Panels

Simple Assembly Instructions - Please keep for future reference

146/1648



## Dimensions

Width - 300cm

Depth - 400cm

Height - 256cm

**Important – Please read these instructions fully before starting assembly**

If you need help or have damaged or missing parts, call the **Customer Helpline: 0845 640 0800**

Retailer: Argos

Address: 489-499 Avebury Boulevard Saxon Gate West, Central Milton Keynes Bucks, MK9, 2NW





# IMPORTANT SAFETY INSTRUCTIONS

**Read all instruction before using and keep for future reference**

- Read these instructions carefully and familiarise yourself with the procedure before assembling the unit.

- Check that you have all the component parts following the list on the page 3 and familiarise yourself with each part before proceeding.

- Take all the fittings out of the plastic bag and separate them into their groups.

- Ensure you have enough space to lay out all the parts before assembly.

- To avoid scratching it is recommended that you assemble the unit on a soft level surface.

- Please **keep children** away when **assembly**. Please keep children under **direct supervision** of adult when **using**.

- **Please do not use the gazebo under windy condition.**

- Always use guy rope and pegs to secure the gazebo when using.

- This Gazebo is not a permanent structure and should be disassembled and stored away after using.

- Do not repack your Gazebo until completely dry.

- We recommend assembly by four persons under light or no wind conditions.

- This Gazebo must not be left erect in windy conditions.

- Keep the Gazebo Fabric away from screws, nails, staples, hooks, etc to avoid damage to the fabric and frame.

- **Warning:** The unit weighs approximately 15.0 kgs.

**Please lift with care.**

## CAUTION

### Fire precautions

- Do not place the Gazebo near lights, fireplaces, gas or electric heaters, candles, radiators, or any other sources of heat, fire or flammable liquids.

- This Gazebo features a Fabric cover that is not flame retardant.

- We recommend caution and common sense when in use.

- This Gazebo can burning.

- Do not use naked flames in or around the Gazebo. We recommend you advise no smoking while inside.

- This Gazebo has no flame retardant cooking area and should not be use to house BBQs or other cooking methods.

### Safety

- To avoid any risks of suffocation to animals or children dispose of the plastic bags immediately.

### Cleaning


















- As with all surfaces clean with a damp cloth and mild detergent, do not use bleach or abrasive products.



# Components - Parts & Fittings

If you have damaged or missing components, call the Customer Helpline: 0845 640 08 00

Please check you have all the parts listed below

<b>1</b>  1 x Gazebo Cover	<b>2</b>  1 x panel w/window	<b>3</b>  1 x panel
<b>4</b>  4 x Baseplate	<b>5</b>  2 x Middle Joint	<b>6</b>  4 x Corner Joint
<b>1#</b>  4 x Top Pole (Φ18 x 1050mm)	<b>2#</b>  4 x Top Pole (Φ18 x 1073mm)	<b>3#</b>  8 x Support Pole (Φ24 x 998mm)
<b>4#</b>  4 x Support Pole (Φ24 x 950mm)	<b>5#</b>  4 x Leg Pole (Φ32 x 1022mm)	<b>6#</b>  4 x Leg Pole (Φ32 x 1022mm)
<b>7#</b>  2 x Supplemental Pole (Φ24x1050mm)	<b>8#</b>  1 x Top Pole (Φ18 x 980mm)	<b>10#</b>  4 x Top Pole (Φ15 x 795mm)
<b>11#</b>  2 x Top Pole (Φ15 x 720mm)	<b>12#</b>  2 x Top Pole (Φ15 x 770mm)	

## Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.



**A** Peg x 17



**B** Guy rope x 4



**C** Curtain Ring x 14



# Assembly Instructions

## Stage 1 – Fitting the Support Poles

### Step 1

Insert Support Pole **4#**  
into the Support Poles **3#**  
Meanwhile, insert Support  
Pole **7#** into Support  
Pole **3#**.  
Ensure all the poles  
are fully inserted and  
secure.  
See fig. 1&2

**IMPORTANT:** Because  
of the size of this unit  
we recommend that it  
is built in the place  
intended for using

**NOTE:** Locate the unit  
on the flat Ground free  
from obstruction, in a  
sheltered area away  
from wind and heavy  
rain as this will  
damage the unit.




Fig.1




Fig.2

### Step 2

Use Corner Joints **6**  
to connect the Support  
Poles. Ensure all the  
poles are fully inserted  
and Secure.

See fig.3.





Fig.3

**NOTE:** It would be  
useful to ask someone  
to help you at this step.



# Assembly Instructions

## Stage 2 – Fitting the Top Poles

### Step 3

Insert Top Poles **2#** into the Top Poles **1#**.  
Meanwhile insert Top Poles **10#** into the Top Poles **12#**. Ensure all the poles are fully inserted and secure. See fig. 4&5




Fig.4




Fig.5

### Step 4

Connect the Top Poles **1#** & **2#** to Corner joint **6** and Centre Connector **5**, then put Tube **8#** into Centre Connector **5** ensuring all poles are fully pushed into joins. See fig 6.

Use hooks provided at the end of pole **10#** and pole **12#** connecting pole **8#** - **3#**. See fig.6.




Fig.6

**NOTE:** It would be useful to ask someone to help you at this step.



# Assembly Instructions

## Stage 3 – Fitting the Gazebo

### Step 5

Connect the top pole 10# & 11#.

Use hools provided at the end of pole 10# and 11# connecting pole 4# and middle joint 5#.

Insert Leg Pole 5# into the unit. Ensure all the poles are fully inserted and secure. See fig. 7.




Fig.7

### Step 6

Carefully place the Gazebo Cover 1 over the assembled roof. Then pull the Gazebo tightly over the assembled roof frame. See fig.8.

a: Use the velcro tapes top frame as shown

**NOTE:** It would be useful to ask someone to help you at this stage.




Fig.8




# Assembly Instructions

## Stage 4 – Fitting the Legs


### Step 7

Insert the Baseplate **4** into the Leg Poles **6#**. Then insert the Leg Poles **6#** into the unit. Ensure all the poles are fully inserted and secure. See fig. 9.



### Step 8

Attach the Gazebo Cover's Hooks into holes on the Leg Poles **6#**. Tighten by moving the Hook to a lower hole. See fig. 12.



**NOTE:** It would be useful to ask someone to help you at this step.



# Assembly Instructions

## Stage 5 – Fitting the Guy Ropes

### Step 9


Attach the D Ring into the Baseplates **4**.  
See fig. 13.

Attach the end of the Guy Rope **B** to the corner of the top cover ring on the Gazebo. Then attaché one end to the peg and drive the Peg into the ground.  
See fig. 15. 16 and 17.

Use the same method as in fig. 14 to fix the other Guy Ropes.

The length of Guy Ropes can be adjusted.  
See fig.17.

**NOTE:** The pegs are for location purpose only. They will not support the unit in high winds. See above instructions.




### Step 10

Caution: Do not assemble or disassemble during strong winds.

Attach the Panels both **2** and **3** at the top using the Curtain Ring **C**, secure the Panels to the Gazebo legs by Velcro Tapes at side  
See fig. 18.19.

Velcro tape of roof stick with the panel both **2** and **3**  
See fig. 20





# Assembly Instructions

## Stage 6 – Fitting the Peg


### Step 11

Insert the pegs **A** to two sides wall in the bottom. See fig.21.

Assembled one is shown as right. See fig.22.

Assemble is complete.

**NOTE:** It would be useful to ask someone to help you at this step.



**Warning:** in heavy wind , if you want to leave the gazebo outside , please remove the side panels



**Important:** always use this product with caution and read the important safety instructions.

If you need help or have damaged or missing parts, call the **Customer Helpline: 0845 640 0800**

Retailer: Argos

Address: 489-499 Avebury Boulevard Saxon Gate West, Central Milton Keynes Bucks, MK9, 2NW