

### **Before you start**



#### **Warnings**

Important: RETAIN FOR FUTURE REFERENCE:READ CAREFULLY

During assembly children should be kept away from the product due to possible risk of injury.

Ensure that this product is fully assembled as illustrated before use.

This product should only be used on firm, level ground.

This product is not designed or to be used as a permanent structure.

All pegs must be fitted.

KEEP AWAY FROM FIRE - Never use fire, including candles and barbecues, inside or near the product.



#### Do's

When you are ready to start, make sure that you have the right tools, plenty of space and a clean, dry area for assembly.

Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to prevent it from scratching.

Check the pack and make sure you have all the parts listed.

To avoid any collapsing or damage, ensure that all connectors & poles are firmly secured in position and fully tightened.

Fold the covers along the seams. The frame must be packed separately from the cover otherwise damage may occur.

During bad weather and winter months the product should be stored in a cool dry place. Before storage ensure that it is clean and dry.

The frames are manufactured using the powder coated steel tubing. When steel is exposed to air and moisture it will rust. Any scratches on the paintwork should be touched up immediately with metal paint, otherwise corrosion may occur.

To clean metal frame, use a soft cloth moistened in lukewarm soap and water. Then buff with a dry clean cloth.

Wipe clean with a soft dry cloth.

To clean wipe with a sponge and warm soapy water then wipe with a dry, clean cloth.

Clean the fabric using warm soapy water only. Do not use solvent based cleaners or detergents as they can bleach or damage the product. The product must be thoroughly dried afterwards to prevent mildew and mould stains from forming. Most stains can be removed with a mild soap.



#### Don't

Do not use this product if parts are missing, damaged or worn.

To avoid damage, do not allow water to collect on the product roof.

Never use a pressure hose or washer to clean the product.

Never use scourers, abrasives or chemical cleaners.

Do not leave the product assembled when there is a risk of high winds as damage will occur to the structure.

#### Number of people required to assemble

Two people to assemble and lift the product into position

#### Time to assemble



15 minutes



#### **Tradesman's tips**

"Hi, look out for me throughout this manual. Wherever you see my picture I will have a handy tip to help you with the assembly of your product."

My first tip is: "Before you start get a cup of tea, sit down and read though these instructions carefully."

And for good measure my second tip is that you will need the following tools to assemble this product, so gather them to hand before you start.

#### **Tools required**



### **Further help**

#### Our promise

We are happy to refund or replace any Tesco produc which falls below the high standard you expect. Just ask any member of staff. This will not effect your statutory rights.

#### Missing parts

If you are missing any fixtures and fittings for your product please contact our customer service team on **08450 264 549** and they will be happy to arrange for a replacement to be sent to you free of charge.

#### Assembly service

If you decide that you do not wish to assemble this product yourself, please contact our team on **08450 264 549** who will be able to provide a quote for assembling this item for you.

### Tesco Self Assembly Furniture Telephone Service

Tesco has enlisted the help of FIRA Service Technicians, the UK's experts on furniture, to provide a helpline for those hitting snags when putting their flat pack item together.

The knowledgeable and patient staff at FIRA can help you and are available to take your call 08.00hrs to 20.00hrs Monday to Friday on: **0845 520 5516\*** 

#### Home service technicians

If you have a fault with your product please contact our customer service team on **08450 264 549**. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we send an independent home service technician to review and repair the product where possible and recommend further action.

#### The Furniture Ombudsman



"Inspiring Consumer Confidence"

As part of our commitment to maintaining high standards and responsible furniture retailing, Tesco is a Full Member of The Furniture Ombudsman. This means that if you're not entirely satisfied with your purchase - and we haven't managed to resolve the problem - you can contact them to look into it for you. By signing up to The Furniture Ombudsman Code of Practice we promise to follow their decisions - ensuring that you get a fair deal. This means that you can buy in complete confidence when selecting your furniture from Tesco.

You should first discuss your complaint with our Customer Service team on **08450 264 549** so that we can try to solve any issues. After that, if you're still not happy you can contact The Furniture Ombudsman at www.thefurnitureombudsman.org

#### You can write to us at


Tesco Stores Ltd, New Tesco House, Delamare Road, Cheshunt, Herts, EN8 9SL, UK

FREEPHONE 0800 50 55 55

To view our full furniture range please visit direct.tesco.com

<sup>\*</sup> Calls are charged at local rates.

### **Getting to know your product**




#### **Components supplied (not actual size)**

1	68.5 x 1.8 cm	х4
2	69 x 1.8 cm	х4
3	29 x 1.8 cm	х4
4	34.5 x 1.8 cm	х4
5	69.5 x 1.8 cm	х4


6	x1
7	<b>x4</b>
8	х4
9	<b>x4</b>
10	<b>x1</b>

www.tesco.com\_



Produced in China for TESCO Stores Ltd. © Tesco 2014.

Every little helps



Produced in China for TESCO Stores Ltd. © Tesco 2014.

Every little helps