
## **Setup Instructions for Haven DCF**

## **Setting Up Your Haven DCF:**

Choose a campsite away from low hanging branches, and clear the ground of sharp objects such as sticks or rocks. Choose a site where water will **drain away** from the shelter. When not using the optional Haven NetTent the use of a footprint is required. Six Moon Designs offers Tyvek or Polycro footprints in various sizes.



- 1. Lay out your **Haven Tarp** with the head pointing into the wind.
- 2. Stake out corners 1 & 2 (Fig. 1).
- 3. Stake out the corners 3 & 4 (Fig. 1). Leave some slack so the canopy can rise when you set your poles.
- 4. Set your hiking pole length to 46" (117cm).
- 5. Under the vestibule, insert the tip of the pole into the pocket at the apex. Keeping the pole vertical place the handle end on the ground.
- 6. Attach hook on the guy line to the loop at the bottom of the vestibule door.
- 7. Pull out guy line so that the vestibule is taut. Stake the guy line at that point (Fig. 1 corner 5 & 6)
- 8. Adjust tension on the guy lines using the line lock at the apex.
- 9. Repeat for the other side.
- 0. Adjust the position of your corner stakes as needed.

## Notes:

- For increased stability in extremely windy conditions, attach guy lines (not included) to each of the side tie-out loops and stake out or tie off to vegetation.
- Check out the FAQ section of our website for more information on the best use of your new shelter.

