


Setup Instructions for Serenity NetTent

Choose a campsite away from low hanging branches, and clear the ground of sharp objects such as sticks or rocks. Avoid contact of the tent's floor with sharp or abrasive objects. The use of a footprint is recommended. Six Moon Designs offers Tyvek or Polycro footprints in various sizes.

Standalone:

1. Set your pole length to 46" (117 cm)
2. Stake out the elastic on corners 1, 2, 3 & 4 (Fig. 1)
3. Insert the tip of your pole in the webbing pocket at the apex and stake out the main guy line. (Fig. 1 location 5)
4. Stake out elastic at location 6 (Fig. 1)



As NetTent inside another shelter:

1. Setup your shelter as per its instructions.
2. Lay out your **Serenity** inside of your shelter with the door facing the vestibule.
3. Attach the corner guy-out hook to the shelter in the corresponding corner. Attach using the D-Ring or simply loop it over the guy-out where it attaches to the tarp.
4. Connect the hook at the peak of the Serenity to the D-Ring at the apex of the shelter or on the Gatewood Cape harness.
5. Wrap the Velcro loop at the apex around the setup pole.

Notes:

- Check out the **FAQ** section of our website for more information on the best use of your new NetTent.