

MODUS

Instruction Manual



IN THE BOX:

Base

Mattress/Quilt
Air-poles/Mesh/Footprint/Stakes

Flysheet

Flysheet/Poles/Tree Straps/Carabiners/Stakes

Base Deluxe

Deluxe Mattress/Quilt
Air-poles/Mesh/Footprint/Stakes

Extras

Connecting Flysheet
Cocoon

VIDEO DEMONSTRATION:

Scan the QR code


or..

Simply search "Crua
Modus Setup Video" on
YouTube




A.) Set up

1. Take out and organize all the contents from the carry bag.
2. Lay down the tent footprint and unroll the mattress. Open the valve at the bottom corner of the mattress to allow air to inflate the mattress. If the mattress does not feel firm enough for you, you can add more air by blowing or with the included pump.



B.) Erecting the Tent


1. Your Modus will come with a bug mesh and air-poles. Attach the bug mesh by zipping it to the base.
2. Un-roll the two air-poles and open the valve for inflation. The air-poles can be inflated by mouth, however, to achieve the correct PSI for the most stability, use the included pump to fill the air-poles.
3. Once inflated, place the air-poles on the Velcro patches on either side of the mattress. The larger air-poles goes on the head end and the smaller on the foot end.
4. Locate the toggles on the bug mesh and place the toggles through the loops on the air-poles.



C.) The Flysheet (i) Covering the Base


1. Place the flysheet over the base tent lining up the air-poles with the center seams of the flysheet.
2. Stake down the head and foot first ensuring that the flysheet is centered appropriately.
3. Stake down the rest of the guy points. Note: the guy points on the left and right side of the flysheet have an elastic rope on them. This is to make it easier for you to get in and out of the tent when using the flysheet.

NOTE: Your Modus flysheet is reversible. Place the reflective side in if you want to direct heat into your tent. Place the reflective side out if you want to reflect the heat away from your tent.




C.) The Flysheet (ii) Using the porch:

1. On the side you will be using as a porch, locate the two circular eyelets and place the included porch poles into the eyelet.
2. Tie a knot at the end of the two extra guy lines provided. Slip the knot over the porch pole and guy down each pole.




D.) Connecting to Another Modus (i) Porch:

1. Simply place a set of poles from one Modus into the eyelets of both.
2. Guy down each pole.



D.) The Hammock

1. Find suitably spaced trees. You should look for trees that are roughly 15 ft (4.5 meters) apart. Your Modus comes with adjustable straps, so there is flexibility on distance.
2. Wrap tree straps around the tree a minimum of 4.5 ft (1.3 meters) off the ground.
3. Pull the end with multiple attach points, through the single loop end. NOTE: based on the size of the tree or distance between trees, you may need to wrap the strap around the tree more than once.
4. Use the included carabiner to attach the tree strap to the webbing at either end of the flysheet.
5. If the hammock feels too saggy, try to move the carabiner up to the next adjustment point. Continue until you find the fit comfort level for you.



D.) Connecting to Another Modus (ii) Sleeping:

1. Place on the extra, connector flyseet.
2. Guy it down securely for protection from the elements or extra privacy.

