

Instruction Manual

IN THE BOX:

Koala/Koala Maxx
Hammock (Pockets and carabiners attached)
Bug Mesh
Buno Bars X2
Pillow
Tree Strap Set

Full-Kit

Tarp
Quilt
Stakes
Gear Hammock

ASSEMBLY, FIRE, & GENERAL PRECAUTIONS FOR YOUR SAFETY

- Please be sure to follow all set-up and safety instructions for your stand.
- Do not allow children to assemble hammocks or hanging chair stands.
- Always observe the maximum weight capacity of the stand.
- Hammock stands and hanging chair stands are not toys.
- Do not use hot appliances or naked flame in or near your hammock or hanging chair.
- Please be sure to follow all set-up and safety instructions for your hammock or hanging chair.



DANGER

Indicates an imminently hazardous situation which, if not avoided, may result in death or serious injury.



WARNING

Indicates an imminently hazardous situation which, if not avoided, may result in death or serious injury.



CAUTION

Indicates an imminently hazardous situation which, if not avoided, may result in death or serious injury.

FLAMMABILITY

Please follow all instructions for your hammock or hanging chair. Keep all flame and heat sources away from your hammock or hanging chair fabric. Any material, even ones treated with flame-resistant chemicals, is not fireproof, the fabric will burn if left in continuous contact with any flame source and could result in serious injury, permanent disability, or death to you or others. For these reasons:

- DO NOT use a naked flame or any fuel-burning devices like matches, lighters, stoves, heaters, grills, lanterns, candles, cooking equipment, or other fuel-burning devices in or near your hammock or hanging chair.
- DO NOT build fires in or near your hammock or hanging chair.
- DO NOT leave campfires unattended.

SEVERE WEATHER HAZARD

In some climatic conditions (for example severe storms, high winds), hammocks and hanging chairs can be heavily blown around causing unpredictable conditions for laying or sitting.

Under such conditions:

- It is not advised to use any hammock or hanging chair in severe storms or heavy winds. Hammocks will fill up with air and become unpredictable and can cause serious injury.
- Severe storms and heavy winds can also cause debris to fly through the air which poses a significant hazard when in a hammock or on a hanging chair.
- DO seek appropriate shelter indoors, for example, in a house, cabin, building, or another secure structure.

PROTECT YOUR CHILDREN

- DO NOT leave children unattended inside a hammock or hanging chair.
- DO NOT allow children to assemble any stand or to hang a chair or hammock.
- DO NOT allow children to play, jump, bounce or swing aggressively on any hammock or hanging chair.
- DO NOT allow children to play with any plastic bags or other packaging material as there is a risk of suffocation.

HAMMOCKS, HANGING CHAIRS & STANDS

- Please read all safety and set-up instructions before using any hammock, hammock tent, hanging chairs, or stands and adhere to the weight restrictions of the products.
- Ensure that tree straps and carabiners are correctly secured to the tree straps OR correctly secured to the stand before entering the hammock, or hanging chair.
- Ensure that the hammock or hanging chair stand is on a at, stable and level surface.
- Ensure that all nuts and bolts are securely tightened.
- Check all nuts, bolts, and other connection periodically or any time you move the hammock or hanging chair stand to ensure they did not loosen as this can cause significant risk.
- Hammocks/tents, hanging chairs, and stands are meant for sitting/laying. DO NOT jump or swing aggressively.

GENERAL PRECAUTIONS

Before using this product, read and fully understand: (1) attached warnings; (2) the instruction manual and all accompanying documentation. Failure to follow these directions can cause an unsafe situation leading to fire, burns, severe injury, or death.

You should carefully consider the conditions of your campsite to reduce the risk of loss or injury to the occupants or tent:



- Make sure you know the fire precaution arrangements on the site.
- Consider the possibility of falling rocks or tree limbs, lightning, flash floods, avalanches, strong winds, and other potential hazards.
- Make sure you correctly hang your hammock or hanging chair and at a safe hanging height.

Basic Kit

(i) Hammock Set Up

1. Find suitably spaced trees:
Lying Position - 15 feet (4.5 metres) apart.
Seated Position - 11 feet (3.5 metres) apart.
2. Wrap the tree straps around the tree and pull through the loop (a). (On thinner trees, try wrapping the straps around a few times). Clip both carabiners into their loops (b).

Height for tree straps from ground:
Lying Position - 4.5 feet (1.3 metres)
Sitting Position - HEAD 6 feet (2 metres)
FOOT 3 feet (1 metre)*



- Place the head of the bar through the eyelet underneath the hammock (c). Now guy out the tabs on the side of the hammock to the ground for the full "Bunoscienn" flat-lay system.
- For the "sitting" position, attach the additional guy line to the tab underneath the hammock and tie behind to a tree trunk, approx. 1 foot (30cm) from the ground (d).
- You will notice that there are two extra blue tabs on the edge of the hammock. These can be used for the Buno Bars when in the seated or lying position. They may be used for increased comfort, depending on individual preference. Please note that the black tabs must always be used for the quilt

**These are approximates and may need to be higher or lower in reality.*

(ii) Attaching the Bug Mesh

- Ensure the spreader bars are out of the hammock.
- Pull both ends of the bug mesh through the hammock, like a sleeve.
- Tie the bug mesh ridgeline to the tree above the tree straps (approx. 1 foot / 30cm above). Make sure that the ridgeline is nice and taught (firm). Adjust if needed.
- Tighten the drawstring end of the bug mesh.
- Insert the Buno Bars underneath the hammock, as shown previously.

Full-Kit

(i) Tarp

- Place the tarp over the Koala making sure that the ridge guy-lines are at the head and foot of the Koala (a).
- Tie the ridge guy-lines around the tree. The higher the guy-lines are tied, the more space you have under the tarp.
- Tie the included guy-lines to the tarp. Stake the guy-lines into the ground.

(ii) Quilt (Underquilt)

- Tie the included guy-lines to each corner of the quilt (b).
- Cross the guy-lines over the Koala, loop them through the opposite side tag and secure the guy-lines to the tree strap.

(iii) Quilt (Cocoon)

- Place the quilt over the Koala and zip it up fully (c).
- Tighten the draw string on the bottom of the quilt.
- Once inside the Koala, grab the quilt and pull it up over you. Tighten draw string to your comfort level.

(iv) Gear Storage

- Slide either end of the guy rope over the carabiner holding up the hammock (d).

