Rocker Ski Rack[™] **Mounting Instructions**



Pencil

Level Drill

ROCKER SKI RACK™ IS TO BE MOUNTED TO WOOD WALL STUDS. NOT RECOMMENDED FOR OUTDOOR APPLICATIONS. INSTALL & USE ROCKER SKI RACK™ AT YOUR OWN RISK.

Included: Needed: **Stud Finder Tape Measure** Ш (4) - 3" Wood Screws (4) - 3/4" Wood Screws • • • 1/8" Drill Bit Rocker Ski Back™ 32" 24" 24" 32" #2 Square Head Driver Mounting Template ۰ ۰ 0 ۰ (1) - Rocker Ski Rack[™] Mounting Template



(1) - Rocker Ski Rack[™]

- 1. Find two wall studs either 24" or 32" inches apart in the area you would like to mount your Rocker Ski Rack™. Use a stud finder or similar method to assist in the locating of studs. Mark the center of the studs. Rocker Ski Rack[™] will only work properly when mounted to wall stude 24" or 32" apart.
- 2. Measure from the ground surface up approximately 5'-6" along the wall studs. Mark this height. Ensure that this mark corresponds to the center of the wall stud.
- 3. Align the top of the Rocker Ski Rack[™] Mounting Template with the 5'-6" marks. Use a level for fine tuning. Align holes of the Rocker Ski Rack™ Mounting Template to the center your wall studs. Transfer the location of the (4) holes to your wall. Rocker Ski Rack™ Mounting Template holes which do not align with wall studs should not be marked.
- 4. At each of the (4) marks, drill a 1/8" diameter pilot hole approximately 2" into your wall studs.
- 5. Align the screw holes of the Rocker Ski Rack™ with pilot holes. Attach the Rocker Ski Rack™ to wall studs with provided 3" wood screws. Do not over-tighten. Infill holes which do not align to wall studs with 3/4" wood screws.



