




## MOUNTING INSTRUCTIONS

# Rocker Ski Rack - Individual

ROCKER SKI RACK™ IS DESIGNED TO BE MOUNTED TO WOOD WALL STUDS, AND IS NOT RECOMMENDED FOR OUTDOOR APPLICATIONS. INSTALL & USE ROCKER SKI RACK™ AT YOUR OWN RISK.

### Included:



Rocker Ski Rack™



(2) Wood Screws

### You'll Need:

Stud Finder	Drill
Tape Measure	1/8" Drill Bit
Pencil	#2 Square Head Driver

### Directions:

1. Find a wall stud where you would like to mount your Rocker Ski Rack™. Use a stud finder to locate the center of the stud. Mark the center of the stud. Rocker Ski Rack™ will only work properly when mounted to a wall stud.
2. Measure from the ground surface up approximately 5'-6" along the wall stud. Mark this height. Ensure that this mark corresponds to the center of the wall stud.
3. Align the top of the Rocker Ski Rack™ with the 5'-6" mark. Align the holes of the Rocker Ski Rack™ to the center your wall stud. Transfer the location of the holes to your wall.
4. At each mark, drill a 1/8" pilot hole approximately 2" into your wall studs.
5. Align the screw holes of the Rocker Ski Rack™ with pilot holes. Attach the Rocker Ski Rack™ to wall stud with provided wood screws. Do not over-tighten.

