

**USER'S MANUAL** 

**XR500** 

WIRELESS HD EARPHONES **IPX7 WATER RESISTANT** 



- TREBLAB XR500
- SILICONE EARTIPS
- EXPANDABLE FOAM EARTIPS Switch between dev

Pause/Play


Vol- Vol+ (BACK/FWD)

- Mic Mute switch
- CHARGING CABLE
- USER'S MANUAL

CARRYING CASE

**SPECIFICATIONS** 

comfort combined with convenience of hands-free operation Bluetooth Version V4.1+ EDR



OPERATION

Pres +- at the same time

Short press the HOME one time

Short/long press Vol- Vol+ (BACK/F

Long press the HOME for 3 second Long press the HOME for 4 second Long press the HOME for up to 7 Short press the HOME one time Short press the HOME one time Long press the HOME for 1 second Double press the HOME one tim Short press the HOMF one time Long press the HOME for 1 secon

off automatically Charge the batteries by:

means the battery is running low. Once this happens, you have about 5-10 minutes of use before the earphones r Using the provided USB/micro USB cable, connect micro USB end of the charging cable to the micro US charging port and the standard USB end to a PC USB port or USB charger.

Red light is on

Blue light is on

Red light flashing twice

Volume+ /- (Press the button one time, the volume will

available Bluetooth devices (check your device's manual you're unsure how to do this). To pair to your Bluetooth enabled device:

HOW TO CONNECT HEADPHONES TO YOUR

Activate the Bluetooth feature on your device and keep within

Press and hold HOME button for approximately 6 seconds unt

3. Using your Bluetooth enabled device, scan/search for available

Bluetooth devices (check your device's manual if you're unsure

3 feet while paring.

how to do this).

red and blue LFDs flash rapidly.

within 3 feet while paring.

until red and blue LEDs flash rapidly.

4. Select TREBLAB XR500 from the device list.

5. If prompted, enter password or PIN No: 0000

If prompted by your device to connect, select Yes

After pairing successfully, the LED indicator will flash blue

he TREBLAB XR500 can only be paired to one device. If you

1. Activate the Bluetooth feature on your device and keep

VOLUME BUTTON

change one level. Headset Hands free A2DP AVRC

Snow, rain, shower, splashing and When fully charged

> Pairing mode Blue and red light flashin

WEARING THE TREBLAB EARPHONES

Using the correct size earbuds is critical for external noise can-

## 1. Use the appropriate size expandable foam ear-tips to help

the earbuds stay in place. XR500 earbuds have a wire that twice. You can then answer the phone or listen to music could be easily fixed around the back of your head (nec the sound becomes intermittent, you hear Low Battery. 8. The next time you switch on the earphones, they will the LED indicator flashes two times every 20 seconds. using a supplied cord minder to ensure additional securing automatically search for and attempt to connect to the last of the earbuds and preventing their loss. It is also common to have different sized ear canals so try the ear tips one at a HOW TO CONNECT HEADPHONES TO MULTIPLE time to find the best fit for each side. Everyone ha individual anatomic features, and to find the most

cellation and securely staying in your ear.

. To seat the ear tip firmly try gently pulling on the outer rim want to use the TREBLAB XR500 to listen to another device of your ear to ease the tip into a comfortable position. You

should notice a drop in ambient noise when the tip is

seated correctly. And when you're listening to music, you'll . The LED indicator will be red while charging. It will turn blue after 1-2 hours. The battery is now fully charged notice more range, especially bass.

## RESTORE FACTORY SETTINGS Using your Bluetooth enabled device, scan/search for

 Please go through troubleshooting steps 1 and 2. Press and hold the HOME button for about 3 seconds while

- charging, until the LEDs flash blue 3 times.
- module and Bluetooth function to listen to music. Pleas **TROUBLESHOOTING**
- 1. Device can't find the Bloetooth earphones
- 7. After pairing successfully, the LED indicator will flash blue Ensure the XR500 is in pairing mode, and LEDs flash blue and
- twice. You can then answer the phone or listen to musi red. Refer to previous section on how to enter pairing mode 8. To connect another device, temporarily switch off If XR500 is in pairing mode and flashes blue and red, but is st Bluetooth on the first device you connected to
- not found by your device, please restart your device and the Repeat steps 1-7 and connect the other device.
- 10. Turn Bluetooth back on for the first device If no connection is made within two minutes after the headse
- has been in the pairing mode, it will exit pairing mode FOR OPTIMAL SOUND QUALITY, THE DISTANCE BETWEEN Y DEVICE AND THE FARPHONES MUST BE LESS THAN 35 FEET. IN AN OPEN SPACE WITH NO SOLID OBSTACLES IN THE WAY.
- the previous section of the manual. If the earphones will not **HOW TO RECONNECT THE EARPHONES** switch off, they can be reset back to normal by charging ther

## 1. After the connection is lost, the XR500 will try to reconne 2. Frequent disconnection and noise

- automatically to any previously paired devices. Ensure your earphones are fully charged. 2. If reconnection does not happen automatically, press the
- HOME button once or reconnect through the Bluetooth men less than 35 feet.
  - your Bluetooth earphones.
- 2. Press and hold HOME button for approximately 6 seconds the previous section of the manual. If you do not use the ear phones for longer than 3 minutes while not connected to a device

Select TREBLAB XR500 from the device list

5. If prompted, enter password or PIN No: 0000

If prompted by your device to connect, select Yes

## 3. Device is connected to earphones, but music is not heard . My device is asking for a password

## connect your Bluetooth earphones to another device

- Restore XR500 to factory settings by following instructions in combustible. The damage to your device can void your . The red LED does not come on while charging manufacturer's warranty.
- This can happen when you have not used the earphones for a long time. Please allow at least 30 minutes to charge and the temperatures (below 37F or above 112F). Extreme Do not dispose of the batteries in a fire as they may explode temperature can cause the deformation of the device an
- 3. Avoid using your device's light close to the eyes of ch 5. Can't connect the earphone to your device

# devices from the list by clicking "Forget this device"

 Turn your device's Bluetooth off then turn it back on: TREBLAR Ensure the distance between your device and the headse XR500 will be deleted.

for a hard reset.

the previous section of the manual.

problem should be solved.

 Ensure nothing is blocking the signal between your device Unplug TREBLAB XR500 from charging cable then power

Restore XR500 to factory settings by following instructions i

- Enter the earphone into the pairing mode and follow Restore XR500 to factory settings by following instructions in
  - instructions for connecting.

# If prompted, please enter 0000 as the password on your

Keep in mind some devices do not have a stereo Bluetooth

# Never disassemble or modify your headset for any reason

- time. We recommend a full charge twice a month to ensure Doing this may cause the headset to malfunction or become battery integrity. Please do not leave the device in hot or cold places, such as it
  - closed car in summer or winter conditions because this will Avoid exposing your device to very cold or very hot reduce the capacity and lifetime of the battery.
- Restore XR500 to factory settings by following instructions in Batteries may also explode if damaged. reduce the charging and life of your device. the previous section of the manual.
- Do not use the device during a thunderstorm. Thunderstor Reset the XR500 to factory settings by following instruction can cause the device to malfunction and increase the risk of electric shock. Go to your device's Bluetooth menu and delete all saved

- Do not charge your headset for much longer than 2-3 hours at a time, because this can lead to reduction in battery capacity. Use Power off device then turn back on. only the provided USB/micro USB cable.
  - Excessive sweating may damage the product. Make sure to wipe the headphones dry before charging.

BATTERY INFORMATION

- Showering
- up to 3 feet for up to 30 minutes

TREBLAB XR500 MEETS IPX-7 WATERPROOF

SUITABLE

Splashing

Rain or Snow

Your device is powered by a rechargeable battery. Unplug the

charger from the electrical plug and the device when not

# UNSUITABLE Swimming

- Diving into wate
- Snorkeling or Scuba Diving
  - High-speed watersports



We really appreciate that you chose TREBLAB as your truste

If for any reason you are not completely satisfied with you

brand of Bluetooth earphones and sincerely hope you enjo If left unused, a fully charged battery will lose its charge over the great sound and comfort TREBLAB provides. We love making our customers happy by providing true value with our

> purchase, let us know immediately and we will do everythin to make sure you are happy.



# WARRANTY

1 Year Parts and Labor Warranty Please visit www.trehlah.com.to.register.YOUR warranty

Manufactured by: Productech Cor www.treblab.co



