



TREBLAB

XR700

USER'S MANUAL

WIRELESS
EARPHONES




XR700

1. TREBLAB XR700
2. Carrying case
3. Silicone eartips
4. Foam eartips
5. User's manual
6. Charging cable
7. Cord minder

Thank you for choosing TREBLAB XR700!

The earphones provide superior sound quality and mobility, combined with light-weight construction and the convenience of hands-free wireless operation. Before using this product, please read this manual.



WEARING YOUR HEADSET

Using appropriate-size eartips and ear-fins is critical for maximum external noise isolation and a snug, secure fit. It is also common to have different sized ear canals, so try the eartips one at a time to find the best fit for each side. Better to try the various sizes of foam and silicone tips supplied with **XR700**.

To seat the **XR700** earbuds firmly, try gently pulling on the outer rim of your ear to ease the tip into a comfortable position. You should notice a drop in ambient noise when the tip is seated correctly. And when you're listening to music, you'll notice more range. Moreover, the **XR700** model is enabled with a flexible earhook you can adjust around your ear for perfect fixation.

Function

Power On

Power Off

Pause / Play

Volume+

Volume-

Next track

Previous track

Answering call

End call

Reject

Redial

Operation

Press and hold  for 2 seconds

Press and hold  for 2 seconds

Press 


Press 


Press 

Press and hold  for 2 seconds

Press and hold  for 2 seconds


Press  during the incoming call

Press  during the conversation

Press and hold  during the incoming call


Press  twice

To change the foam ear-tips:



1. Put the rubber inner part of the foam ear-tip on the top of the nozzle.
2. Rotate and push down the ear nozzle, trying to forcedly "wrap" it to the inner rubber part of the ear tip, with a kind of screwing movement.

To change the silicone ear-tips:



1. Turn over the ear-tip upper cover.
2. Rotate and firmly push the ear-tip tube to cover the ear-tip pillar.
3. Turn the ear-tip upper cover back on the nozzle.

SETTING UP YOUR TREBLAB XR700

Turn ON

Press and hold the POWER button for 3 seconds. You will hear a "Power ON" voice prompt, and the blue & red LED light will start flashing.

Turn OFF

Press and hold the POWER button for 3 seconds. You will hear a "Power OFF" voice prompt, and the flashing blue LED light will go off.

Pairing

Make sure **TREBLAB XR700** is fully charged and turned OFF.

1. Press and hold the POWER button on the right earbud. You will hear the "Power ON" voice prompt, and "PAIRING" a few seconds later (LED will flash red and blue rapidly). Release your finger.
2. Activate the wireless connection option on your smart device and keep it within 3 feet / 1 meter while pairing.
3. Using your smart device, scan/search for available devices.
4. Select **TREBLAB XR700** from the device list.
5. If prompted for the password, enter "0000".
6. Once **XR700** is successfully paired and connected, you will hear a "CONNECTED" voice prompt, and the LED will start flashing blue every 6 seconds.

TREBLAB XR700 can be paired to only 1 device at a time. The system will prevent pairing with any other devices. To connect **XR700** to another device:

1. Temporarily switch OFF the wireless mode on the first device you connected to.
2. Repeat steps 1-6 and connect the other device.
3. Turn wireless mode back ON for the first device.

When you turn the earbuds ON, they will try to reconnect with the most-recently connected device. If reconnection does not happen automatically, the earbuds will try to find the next device in the pairing list.

AUDIO PLAYBACK

- To pause and resume playback, press the POWER button.
- To adjust volume, short press the Volume + button to turn the volume up and Volume - button to turn the volume down.
- To change tracks on the **XR700**, press and hold the Volume + button to play the next track and Volume - button to play the previous track.

PHONE CALLS MANAGEMENT

TREBLAB XR700 can be used to make and receive phone calls when connected wirelessly. Audio playback will be paused during calls.

To Answer Call	Press the POWER button during the incoming call.
To Reject Call	Press and hold the POWER button for 2 seconds.
To End Call	Press the POWER button while on the phone.
To Redial	Press the POWER button twice.

TROUBLESHOOTING

Problem

Solution

❓ Not powering on

Make sure the headset is fully charged. Charge for 2 hours, if necessary.

Reset the earphones: press and hold the POWER button for 3 seconds while charging, until the LED flashes blue 3 times.

❓ Not pairing

Make sure the speaker is not paired with any other device, as it can only pair with one device at a time.

Press and hold the POWER button for about 3 seconds while charging, until the LED flashes blue 3 times. This will force the headset to forget previously paired devices. Repeat the steps for pairing as previously described.

Alternatively, disconnect the device from your headset and remove **TREBLAB XR700** from your device's pairing list. Try to pair again.

❓ Not finding a wireless driver on your laptop

Make sure your laptop supports wireless connections. If it doesn't, you will need an external wireless USB adapter compatible with your laptop. For further details, consult with your laptop manufacturer.

❓ Frequent disconnection and noise

Ensure that the distance between your device and the headset is less than 30 feet / 10 meters.

Ensure that nothing is blocking the signal between your device and the **XR700**.

Check if the music is paused.

Check if the volume level is set both on the source device and on the speaker.

Check if the headset is running out of power.

RESTORE FACTORY SETTINGS

To restore the earphones back to factory settings:

1. Put the headset to charging.
2. Press and hold the POWER button for 3 seconds while charging, until the LED flashes blue 3 times.
3. Now the earphones are restored back to factory settings and ready to be paired again.

CHARGING

One full battery charge provides up to 4 hours of playing time at maximum volume, and up to 8 hours at medium volume. When the battery is running low, you will hear a "BATTERY LOW" voice prompt.

To charge the earbuds, plug one end of the supplied cable into the Micro-USB charging port under the rubber cover of the right earbud. Plug the other end of the charging cable into a standard USB port. It takes up to 3 hours to fully charge.

The LED light will turn on red while charging. The red light will turn blue when the earbuds are fully charged.

Be sure to use a 5V DC, 0.5-2 A adapter or charger. Using a power source with lower power will increase the overall charging time. Maximize the battery lifespan by charging your speaker through a computer's USB port.

Unplug **XR700** from the charging cable and the cable itself from the power source when not in use.

If the headset is left unused, even the fully charged battery will lose its charge over time. We recommend fully charging the **TREBLAB XR700** at least twice a month to maintain sufficient battery life.

SAFETY RULES

- ❗ Don't disassemble or modify your earbuds for any reason. Doing this may cause the earbuds to malfunction or become combustible. The damage to your device can void the manufacturer's warranty.
- ❗ Make sure the headset is completely dry before charging. Charging a wet device may cause serious damage.
- ❗ Clean only with a dry cloth.
- ❗ Avoid exposing **TREBLAB XR700** to extreme temperatures (below 37°F / 3°C or above 112°F / 45°C). Extreme temperatures can cause deformation of **XR700** components and reduce battery life and the lifespan of your headset.
- ❗ Don't put the device's LED lights close to humans' or animals' eyes.

- ⓘ Do not use **XR700** during a thunderstorm. Thunderstorms can cause serious malfunction and increase the risk of electric shock.

RECYCLING

The earphones can be recycled, and they should be in order to keep our planet clean. Where should you bring them?

In the **US**, there are a couple of options:

1. Best Buy has a recycling program. Just take the broken earbuds with you next time you visit a BestBuy store. This link will help you to find the best location:
<https://www.bestbuy.com/site/store-locator/>
2. Check for other possible locations next to you on these websites (just enter your ZIP to find a location):
<https://search.earth911.com>
<https://recyclenation.com/find>
<https://www.cta.tech/Consumer-Resources/Greener-Gadgets>

In **Canada**, please visit the link below for help:

<https://thinkreuse.net>

In **UK**, please visit the link below for help:

<https://www.recycle-more.co.uk/>

SPECIFICATIONS

Battery	Up to 9 hours playing time (60% volume) Up to 4 hours (100% volume) 100 mAh 3.7 V, rechargeable Li-Ion Input 5 V / 1 A
Charging time	up to 2 hours
Wireless connection version	5.0, HFP v1.7, A2DP v1.3, AVRCPv1.5
Signal Range	33 ft / 10 m
Frequency response	20 Hz—2 KHz
Water resistance	IPX7
Charging port	Micro-USB
Color	Black
Dimensions	1.41 x 1.3 x 0.35 in / 36 x 33 x 9 mm
Weight	22 g / 0.77 oz / 0.05 lb

TREBLAB XR700 MEETS IPX7 WATERPROOF STANDARD

SUITABLE	UNSUITABLE
Rain or snow	Swimming
Splashing	Diving into water
Showering	Snorkeling or Scuba Diving
Incidental exposure to water of up to 3 feet / 1 meter for up to 30 min.	High-speed watersports
Outdoor sports	Sauna and steam bath

THANK YOU

We truly appreciate that you chose **TREBLAB** as your trusted brand of wireless earphones and sincerely hope you enjoy the great sound and seamless usability **TREBLAB XR700** provides. We love making our customers happy by providing true value with our products. If for any reason you are not completely satisfied with your purchase or have any questions, please let us know by contacting us at support@treblab.com. We care about our customers more than anything and are always here to serve you.

1 YEAR WARRANTY

Parts and Labor Warranty.

Please visit www.treblab.com
to register YOUR warranty.


Manufactured by:
Productech Corp www.treblab.com

Contact us: support@treblab.com
+1 (315) 883-2603



TREBLAB **XR700**

WIRELESS EARPHONES



Made in China