


Tab Secure


SLIM

WALL MOUNT

What's In The Box




Dimension Enclosures




Installation Guide


STEP 1: Attach Tab Secure enclosure to wall mount plate. Remove adhesive backing paper from wall plate. Allign wall plate on back of enclosure. Ensure slot on

STEP 2: Feed power cable through back of case



wall







Installation Guide

STEP 3: Attach Tab Secure to wall

Use the 4 x self tapping wood screws to fix your Tab Secure to the wall.




STEP 4: Firmly insert each of the four Fit Kit rubber corner pieces into the case by aligning with the Positioning Pins.



Insert Ipad or Tablet


STEP 5: Connect the charge cable to the tablet, then insert your tablet into the Fit Kit corner pieces. It should sit neat and snug.


STEP 6: First, peel the brown protective seal from one side of the Acrylic Faceplate. Then insert the Acrylic Faceplate over the top of your tablet with the black, shiny side facing up.



Attach The Faceplate

STEP 7: The last step is to lock-down the Metal Face Cover to secure and protect your tablet. First, position the two Fixing Hooks into the Case (opposite side of the Key Lock). Then pop in the other end. The Faceplate should click into the Case and sit flush.






Push To Lock

STEP 8: To complete the setup of your kiosk and ensure your device is secure, make sure to push in the lock-pin. To unlock use the 2 keys provided.

When the lock-pin stands out, it means your kiosk is open



Please note: The Pair of Keys are use to unlock the kiosk.

