



Part No.	Part Name
1a	Bull Barrel 22 LR
1b	Bull Barrel 17 HMR
1c	Bull Barrel 22 WMR
2a	Barrel 22 LR
2b	Barrel 17 HMR
2c	Barrel 22 WMR
3	Bull Barrel Muzzle Screw
4	Muzzle Screw
5	Receiver
6	Rail
7	Rail Screw
8	Lock Washer
9	Ejector
10	Extractor Pin
11	Extractor Spring
12	Extractor
13	Bolt Body
14	Safety Lever
15	Bolt Handel
16	Bolt Handel Ball
17	Firing Pin

Part No.	Part Name
18	Firing Pin Spring
19	Firing Pin Spring Retainer
20	Barrel Rest Screw
21	Barrel Rest
22	Stock
23	Action Screw
24	Magazine 22 WMR / 17 HMR
25	Magazine 22 LR
26	Magazine Release Spring
27	Spiral Cutting Pin
28	Magazine Release
29	Magazine Insert
30	Sear Pin
31	Trigger Pin
32	Ejector Screw
33	Sear Bolt
34	Sear Spring
35	Sear
36	Trigger Spring
37	Trigger Adjustment Screw
38	Trigger