



MOUNTAIN
ACTIVE CO.

EARTHLIGHT

USER MANUAL




WELCOME



Our mission is to create stylish, versatile and highly functional life accessories for people like us.

Here is our manual to help set up your Earthlight new watch. The process should only take you a few minutes.

HOW TO SET THE TIME



1 Pull the crown out to the 1st click position when the second hand is at the 12 o'clock position.

2 Turn the crown to set the hour and minute hands

3 Push the crown back to the normal position.

WATER RESISTANCE RATINGS

All our watches are tested to 10 ATM/100M/300FT

This means they are suitable for

1. Rain, splashes
2. Showering, swimming
3. Surfing, Snorkeling, Spearfishing*

WATCH CARE

*Rinse watch with soap and water after exposure to salt water or sand.

Replace the battery at least every two years (except solar, which never needs replacing). Dead or low batteries left in a watch may leak and destroy the movement of your watch. If you have a water resistant watch, know that the water resistancy is attained using rubber or plastic seals which will deteriorate under normal conditions and reduce the water resistancy of your watch. These seals should be checked by an authorized jeweler at least every two years to ensure the rated water resistancy. Do not expose your watch to extreme temperatures (over 60°C or 140°F, under -10°C or 14°F). No hot tubs or saunas. Avoid extreme shocks.

WARRANTY INFO

Mountain Active Co offers a 1 year limited warranty from the date of purchase on defects in workmanship. This means that if the materials in your watch aren't right or if the watch isn't put together correctly, we will repair or replace it, at our discretion.

The warranty does not cover normal wear, tear and aging to mineral crystals, watch case, strap and batteries, nor does it cover loss or theft. You will void your warranty if you open your caseback, push the buttons underwater, or forget to push in the crown and expose your watch to moisture.

PROBLEMS?

Email team@Mountainactive.com and we'll do all we can to resolve the problem.

COUNTRY OF ORIGIN

Mountain Active Co watches are designed in Australia and Made in China.